


F-04
RELAY AND FUSE BLOCK



NO.	FUSE NAME	FUSE RATING	NO.	RELAY NAME
F70	[CLEAN/ROOF]	[20A]	R70	COOLING FAN RELAY NO.1 {FAN MAIN}
F71	A/C	10A	R71	COOLING FAN RELAY NO.2 {FAN2}
F72	[TRAILER]	[20A]		
F73	[P.SEAT(P)]	[30A]		
F74	GLOW SIG	10A		
F75	ST SIG	5A		

{ } NAME INDICATED ON FUSE BOX COVER
[] IF EQUIPPED