

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
R01 FRONT SUSPENSION (STRUT)				
COIL SPRING, R&R	One side	R0101ARX	0.5	◆Front shock absorber assembly, R&R
COIL SPRING, R&R	Both sides	R0101BRX	0.8	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	One side	R0102ARX	0.5	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	Both sides	R0102BRX	0.7	◆Front shock absorber assembly, R&R
MOUNT BLOCK, R&R	One side	R0103ARX	0.5	◆Front shock absorber assembly, R&R
MOUNT BLOCK, R&R	Both sides	R0103BRX	0.7	◆Front shock absorber assembly, R&R
BEARING, R&R	One side	R0104ARX	0.5	◆Front shock absorber assembly, R&R
BEARING, R&R	Both sides	R0104BRX	0.7	◆Front shock absorber assembly, R&R
BOUND BUMPER, R&R	One side	R0105ARX	0.5	◆Front shock absorber assembly, R&R
BOUND BUMPER, R&R	Both sides	R0105BRX	0.7	◆Front shock absorber assembly, R&R
LOWER ARM, R&R	One side	R0106ARX	0.5	
LOWER ARM, R&R	Both sides	R0106BRX	0.7	
FRONT SHOCK ABSORBER, R&R	One side	R0109ARX	0.5	
FRONT SHOCK ABSORBER, R&R	Both sides	R0109BRX	0.7	
R04 FRONT STABILIZER & CROSSMEMBER				
STABILIZER BAR, R&R		R0401XRX	1.6	◆Front crossmember assembly, R&R◆ Rubber bush and/or plate [Body side] (R0403), R&R
STABILIZER CONTROL BOLT [CONTROL LINK] AND/OR RUBBER BUSH, R&R	One side	R0402ARX	0.3	
STABILIZER CONTROL BOLT [CONTROL LINK] AND/OR RUBBER BUSH, R&R	Both sides	R0402BRX	0.4	
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	One side	R0403ARX	1.6	◆Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	Both sides	R0403BRX	1.6	◆Front crossmember assembly, R&R
CROSSMEMBER, R&R	2WD	R0404ARX	1.8	
CROSSMEMBER, R&R	4WD	R0404BRX	1.7	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
R05 REAR SUSPENSION (STRUT & MULTI-LINK)				
COIL SPRING, R&R	One side	R0501ARX	0.4	
COIL SPRING, R&R	Both sides	R0501BRX	0.6	
SPRING UPPER SEAT, R&R	One side	R0502ARX	0.4	◆Coil spring (R0501), R&R
SPRING UPPER SEAT, R&R	Both sides	R0502BRX	0.6	◆Coil spring (R0501), R&R
BOUND STOP RUBBER, R&R	One side	R0503ARX	0.5	
BOUND STOP RUBBER, R&R	Both sides	R0503BRX	0.7	
TRAILING LINK, R&R	One side	R0504ARX	0.5	
TRAILING LINK, R&R	Both sides	R0504BRX	0.8	
MOUNTING RUBBER, R&R	One side	R0505ARX	0.5	
MOUNTING RUBBER, R&R	Both sides	R0505BRX	0.7	
LATERAL LINK [FRONT], R&R	One side	R0506ARX	0.4	
LATERAL LINK [FRONT], R&R	Both sides	R0506BRX	0.5	
REAR SHOCK ABSORBER, R&R	One side	R0508ARX	0.4	
REAR SHOCK ABSORBER, R&R	Both sides	R0508BRX	0.5	
LOWER ARM, R&R	One side	R0510ARX	0.4	◆Coil spring (R0501), R&R
LOWER ARM, R&R	Both sides	R0510BRX	0.6	◆Coil spring (R0501), R&R
UPPER ARM, R&R	Assembly,One side,2WD	R0513ARX	1.7	◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Assembly,One side,4WD	R0513BRX	2.2	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Assembly,Both sides,2WD	R0513CRX	1.7	◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Assembly,Both sides,4WD	R0513DRX	2.3	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Bushing,One side,2WD	R0513ERX	1.9	◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Bushing,One side,4WD	R0513FRX	2.4	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Bushing,Both sides,2WD	R0513GRX	2.1	◆Rear crossmember assembly, D&C
UPPER ARM, R&R	Bushing,Both sides,4WD	R0513HRX	2.6	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
DUST BOOT, R&R	One side	R0517ARX	0.4	
DUST BOOT, R&R	Both sides	R0517BRX	0.6	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
R08 REAR STABILIZER & CROSSMEMBER				
STABILIZER BAR, R&R	2WD	R0801ARX	0.5	
STABILIZER BAR, R&R	4WD	R0801BRX	2.3	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	2WD,One side	R0802ARX	0.4	
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	2WD,Both sides	R0802BRX	0.5	
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	4WD,One side	R0802CRX	2.2	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	4WD,Both sides	R0802DRX	2.3	◆Propeller shaft assembly (L0101), R&R◆Rear crossmember assembly, D&C
STABILIZER CONTROL LINK [CONTROL ROD], R&R	One side	R0803ARX	0.2	
STABILIZER CONTROL LINK [CONTROL ROD], R&R	Both sides	R0803BRX	0.3	
CROSSMEMBER, R&R	2WD	R0804ARX	2.0	◆Middle pipe (F0207), R&R◆Coil spring (R0501), R&R
CROSSMEMBER, R&R	4WD	R0804BRX	3.8	◆Propeller shaft assembly (L0101), R&R◆Middle pipe (F0207), R&R◆Coil spring (R0501), R&R