

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
A01 MAINTENANCE AND ADJUSTMENTS				
IDLE SPEED, CHECK AND ADJUST		A0106XAX	0.4	
IGNITION TIMING, CHECK AND ADJUST		A0108XAX	0.4	
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wired type 4-wheel alignment tester used,Front	A0109AAX	1.3	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wired type 4-wheel alignment tester used,Rear	A0109BAX	1.0	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wired type 4-wheel alignment tester used,Front and rear	A0109CAX	1.4	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wireless type 4-wheel alignment tester used,Front	A0109DAX	0.8	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wireless type 4-wheel alignment tester used,Rear	A0109EAX	0.6	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Wireless type 4-wheel alignment tester used,Front and rear	A0109FAX	1.0	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Except 4-wheel alignment tester used,Front,Steering angle	A0109GAX	0.6	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Except 4-wheel alignment tester used,Front,Toe-in	A0109HAX	0.6	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Except 4-wheel alignment tester used,Front,Steering angle and toe-in	A0109JAX	1.0	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK AND ADJUST	Except 4-wheel alignment tester used,Rear	A0109KAX	0.7	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK	Wired type 4-wheel alignment tester used,Front and rear	A0109ACX	0.9	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK	Wireless type 4-wheel alignment tester used,Front and rear	A0109BCX	0.5	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK	Except 4-wheel alignment tester used,Front	A0109CCX	0.6	◆Tire pressure, Adjust
FRONT AND/OR REAR WHEEL ALIGNMENT, CHECK	Except 4-wheel alignment tester used,Rear	A0109DCX	0.6	◆Tire pressure, Adjust
WHEEL, BALANCE	On the car,One	A0112AAX	0.3	◆Tire pressure, Adjust
WHEEL, BALANCE	On the car,Two	A0112BAX	0.4	◆Tire pressure, Adjust
WHEEL, BALANCE	On the car,Three	A0112CAX	0.5	◆Tire pressure, Adjust

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
WHEEL, BALANCE	On the car,All	A0112DAX	0.6	◆Tire pressure, Adjust
WHEEL, BALANCE	Off the car,One	A0112EAX	0.4	◆Tire pressure, Adjust
WHEEL, BALANCE	Off the car,Two	A0112FAX	0.5	◆Tire pressure, Adjust
WHEEL, BALANCE	Off the car,Three	A0112GAX	0.6	◆Tire pressure, Adjust
WHEEL, BALANCE	Off the car,All	A0112HAX	0.7	◆Tire pressure, Adjust
EXHAUST MANIFOLD NUT, RETIGHTEN	2WD	A0113ATX	0.9	◆Exhaust manifold heat insulator (F0213), R&R
EXHAUST MANIFOLD NUT, RETIGHTEN	4WD	A0113BTX	1.5	◆Exhaust manifold heat insulator (F0213), R&R
SPARK PLUG [ALL], CLEAN AND CHECK		A0114XCX	0.4	◆Spark plug (G0102), R&R
HEADLIGHT, AIM	One side	A0115AAX	0.3	
HEADLIGHT, AIM	Both sides	A0115BAX	0.4	
BRAKE LINES, AIR BLEED		A0120XRX	0.4	
FRONT DOOR GLASS AND/OR WINDOW REGULATOR, ADJUST	One side	A0127AAX	0.3	
FRONT DOOR GLASS AND/OR WINDOW REGULATOR, ADJUST	Both sides	A0127BAX	0.5	
REAR DOOR GLASS AND/OR WINDOW REGULATOR, ADJUST	One side	A0128AAX	0.3	
REAR DOOR GLASS AND/OR WINDOW REGULATOR, ADJUST	Both sides	A0128BAX	0.5	
AA5 SCHEDULED MAINTENANCE SERVICE (For General) (NOT COVERED BY MANUFACTURER'S WARRANTY)				
10,000 KILOMETERS [6,250 MILES] OR 6 MONTHS	SKYACTIV-G 2.5	AA532AMX	0.9	
10,000 KILOMETERS [6,250 MILES] OR 6 MONTHS	SKYACTIV-D 2.2	AA532BMX	0.8	
20,000 KILOMETERS [12,500 MILES] OR 12 MONTHS	SKYACTIV-G 2.5	AA533AMX	1.5	
20,000 KILOMETERS [12,500 MILES] OR 12 MONTHS	SKYACTIV-D 2.2	AA533BMX	1.3	
30,000 KILOMETERS [18,750 MILES] OR 18 MONTHS	SKYACTIV-G 2.5	AA534AMX	0.9	
30,000 KILOMETERS [18,750 MILES] OR 18 MONTHS	SKYACTIV-D 2.2	AA534BMX	0.8	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
40,000 KILOMETERS [25,000 MILES] OR 24 MONTHS	SKYACTIV-G 2.5,Except for Georgia and Armenia	AA535AMX	1.8	
40,000 KILOMETERS [25,000 MILES] OR 24 MONTHS	SKYACTIV-G 2.5,For Georgia and Armenia	AA535BMX	1.7	
40,000 KILOMETERS [25,000 MILES] OR 24 MONTHS	SKYACTIV-D 2.2	AA535CMX	2.4	
50,000 KILOMETERS [31,250 MILES] OR 30 MONTHS	SKYACTIV-G 2.5	AA536AMX	0.9	
50,000 KILOMETERS [31,250 MILES] OR 30 MONTHS	SKYACTIV-D 2.2	AA536BMX	0.8	
60,000 KILOMETERS [37,500 MILES] OR 36 MONTHS	SKYACTIV-G 2.5,Except for Georgia and Armenia,Except for Taiwan	AA537AMX	2.4	
60,000 KILOMETERS [37,500 MILES] OR 36 MONTHS	SKYACTIV-G 2.5,Except for Georgia and Armenia,For Taiwan	AA537BMX	1.5	
60,000 KILOMETERS [37,500 MILES] OR 36 MONTHS	SKYACTIV-G 2.5,For Georgia and Armenia,2WD	AA537CMX	2.4	
60,000 KILOMETERS [37,500 MILES] OR 36 MONTHS	SKYACTIV-G 2.5,For Georgia and Armenia,4WD	AA537DMX	2.5	
60,000 KILOMETERS [37,500 MILES] OR 36 MONTHS	SKYACTIV-D 2.2	AA537EMX	1.3	
70,000 KILOMETERS [43,750 MILES] OR 42 MONTHS	SKYACTIV-G 2.5	AA538AMX	0.9	
70,000 KILOMETERS [43,750 MILES] OR 42 MONTHS	SKYACTIV-D 2.2	AA538BMX	0.8	
80,000 KILOMETERS [50,000 MILES] OR 48 MONTHS	SKYACTIV-G 2.5,Except for Georgia and Armenia,Except for Taiwan	AA539AMX	1.8	
80,000 KILOMETERS [50,000 MILES] OR 48 MONTHS	SKYACTIV-G 2.5,Except for Georgia and Armenia,For Taiwan	AA539BMX	2.7	
80,000 KILOMETERS [50,000 MILES] OR 48 MONTHS	SKYACTIV-G 2.5,For Georgia and Armenia	AA539CMX	1.7	
80,000 KILOMETERS [50,000 MILES] OR 48 MONTHS	SKYACTIV-D 2.2	AA539DMX	2.4	
90,000 KILOMETERS [56,250 MILES] OR 54 MONTHS	SKYACTIV-G 2.5	AA540AMX	0.9	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
90,000 KILOMETERS [56,250 MILES] OR 54 MONTHS	SKYACTIV-D 2.2	AA540BMX	0.8	
100,000 KILOMETERS [62,500 MILES] OR 60 MONTHS	SKYACTIV-G 2.5	AA541AMX	1.5	
100,000 KILOMETERS [62,500 MILES] OR 60 MONTHS	SKYACTIV-D 2.2	AA541BMX	1.3	
110,000 KILOMETERS [68,750 MILES] OR 66 MONTHS	SKYACTIV-G 2.5	AA542AMX	0.9	
110,000 KILOMETERS [68,750 MILES] OR 66 MONTHS	SKYACTIV-D 2.2	AA542BMX	0.8	
120,000 KILOMETERS [75,000 MILES] OR 72 MONTHS	[SKYACTIV-G 2.5,Except for Taiwan,2WD,Captain type second-row seat]/[SKYACTIV-G 2.5,Except for Taiwan,2WD,Bench type second-row seat,RHD]	AA543AMX	2.8	
120,000 KILOMETERS [75,000 MILES] OR 72 MONTHS	[SKYACTIV-G 2.5,Except for Taiwan,2WD,Bench type second-row seat,LHD]/[SKYACTIV-G 2.5,Except for Taiwan,4WD]	AA543BMX	2.8	
120,000 KILOMETERS [75,000 MILES] OR 72 MONTHS	SKYACTIV-G 2.5,For Taiwan	AA543CMX	1.9	
120,000 KILOMETERS [75,000 MILES] OR 72 MONTHS	SKYACTIV-D 2.2	AA543DMX	2.4	
130,000 KILOMETERS [81,250 MILES] OR 78 MONTHS	SKYACTIV-G 2.5	AA544AMX	0.9	
130,000 KILOMETERS [81,250 MILES] OR 78 MONTHS	SKYACTIV-D 2.2	AA544BMX	0.8	
140,000 KILOMETERS [87,500 MILES] OR 84 MONTHS	SKYACTIV-G 2.5	AA545AMX	1.5	
140,000 KILOMETERS [87,500 MILES] OR 84 MONTHS	SKYACTIV-D 2.2	AA545BMX	1.3	
150,000 KILOMETERS [93,750 MILES] OR 90 MONTHS	SKYACTIV-G 2.5	AA546AMX	0.9	
150,000 KILOMETERS [93,750 MILES] OR 90 MONTHS	SKYACTIV-D 2.2	AA546BMX	0.8	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
160,000 KILOMETERS [100,000 MILES] OR 96 MONTHS	SKYACTIV-G 2.5, Except for Georgia and Armenia, Except for Taiwan	AA547AMX	1.8	
160,000 KILOMETERS [100,000 MILES] OR 96 MONTHS	SKYACTIV-G 2.5, Except for Georgia and Armenia, For Taiwan	AA547BMX	2.7	
160,000 KILOMETERS [100,000 MILES] OR 96 MONTHS	SKYACTIV-G 2.5, For Georgia and Armenia	AA547CMX	1.7	
160,000 KILOMETERS [100,000 MILES] OR 96 MONTHS	SKYACTIV-D 2.2	AA547DMX	2.4	
SELF-TEST WITH MAZDA MODULAR DIAGNOSTIC SYSTEM [M-MDS]	SKYACTIV-G 2.5	AA551AMX	0.2	
AA9 SCHEDULED MAINTENANCE SERVICE (For ADR) Basic interval 10,000 Kilometers (NOT COVERED BY MANUFACTURER'S WARRANTY)				
10,000 KILOMETERS OR 12 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA932XMX	1.5	
10,000 KILOMETERS OR 12 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA932AMX	1.4	
20,000 KILOMETERS OR 24 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA933XMX	2.9	
20,000 KILOMETERS OR 24 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA933AMX	2.0	
30,000 KILOMETERS OR 36 MONTHS	For New Zealand	AA934XMX	1.4	
40,000 KILOMETERS OR 48 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA935XMX	2.9	
40,000 KILOMETERS OR 48 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA935AMX	2.1	
50,000 KILOMETERS OR 60 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA936XMX	1.5	
50,000 KILOMETERS OR 60 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA936AMX	1.4	
60,000 KILOMETERS OR 72 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA937XMX	2.8	
60,000 KILOMETERS OR 72 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA937AMX	2.0	
70,000 KILOMETERS OR 84 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA938XMX	1.5	
70,000 KILOMETERS OR 84 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA938AMX	1.4	
80,000 KILOMETERS OR 96 MONTHS	SKYACTIV-D 2.2, VIN Serial No.100001-200000, For New Zealand	AA939XMX	2.9	
80,000 KILOMETERS OR 96 MONTHS	SKYACTIV-D 2.2, VIN Serial No.200001-, For New Zealand	AA939AMX	2.9	
80,000 KILOMETERS OR 96 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA939BMX	2.1	
90,000 KILOMETERS OR 108 MONTHS	For New Zealand	AA940XMX	1.4	
100,000 KILOMETERS OR 120 MONTHS	SKYACTIV-D 2.2, For New Zealand	AA941XMX	3.2	
100,000 KILOMETERS OR 120 MONTHS	SKYACTIV-G 2.5, For New Zealand	AA941AMX	2.3	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
110,000 KILOMETERS OR 132 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA942XMX	1.5	
110,000 KILOMETERS OR 132 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA942AMX	1.4	
120,000 KILOMETERS OR 144 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA943XMX	2.8	
120,000 KILOMETERS OR 144 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA943AMX	2.3	
130,000 KILOMETERS OR 156 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA944XMX	1.5	
130,000 KILOMETERS OR 156 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA944AMX	1.4	
140,000 KILOMETERS OR 168 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA945XMX	2.9	
140,000 KILOMETERS OR 168 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA945AMX	2.0	
150,000 KILOMETERS OR 180 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA946XMX	1.8	
150,000 KILOMETERS OR 180 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA946AMX	2.8	
160,000 KILOMETERS OR 192 MONTHS	<i>SKYACTIV-D 2.2, VIN Serial No.100001-200000,For New Zealand</i>	AA947XMX	2.9	
160,000 KILOMETERS OR 192 MONTHS	<i>SKYACTIV-D 2.2, VIN Serial No.200001-,For New Zealand</i>	AA947AMX	2.9	
160,000 KILOMETERS OR 192 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA947BMX	2.1	
170,000 KILOMETERS OR 204 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA948XMX	1.5	
170,000 KILOMETERS OR 204 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA948AMX	1.4	
180,000 KILOMETERS OR 216 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA949XMX	2.8	
180,000 KILOMETERS OR 216 MONTHS	<i>SKYACTIV-G 2.5,For New Zealand</i>	AA949AMX	2.0	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
190,000 KILOMETERS OR 228 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA950XMX	1.5	
<i>190,000 KILOMETERS OR 228 MONTHS</i>	<i>SKYACTIV-G 2.5,For New Zealand</i>	<i>AA950AMX</i>	<i>1.4</i>	
200,000 KILOMETERS OR 240 MONTHS	<i>SKYACTIV-D 2.2,For New Zealand</i>	AA951XMX	3.2	
<i>200,000 KILOMETERS OR 240 MONTHS</i>	<i>SKYACTIV-G 2.5,For New Zealand</i>	<i>AA951AMX</i>	<i>2.5</i>	
AC1 MAINTENANCE AND ADJUSTMENTS (NOT COVERED BY MANUFACTURER'S WARRANTY)				
COMPRESSION PRESSURE, CHECK	SKYACTIV-G 2.5	AC101ACX	0.8	◆Spark plug (G0102), R&R
COMPRESSION PRESSURE, CHECK	SKYACTIV-D 2.2	AC101XCX	0.9	◆Glow plug (G0701), R&R
CHARCOAL CANISTER, CHECK		AC103XCX	0.4	
POSITIVE CRANKCASE VENTILATION [PCV] VALVE, CHECK		AC105XCX	0.9	◆Intake manifold gasket (F0102), R&R
THREE WAY SOLENOID VALVE OR EGR SOLENOID VALVE, CHECK		AC113XCX	0.4	
EGR VALVE, CHECK		AC114XCX	0.4	
FUEL EVAPORATIVE LINE, CHECK FOR LEAK		AC116XCX	0.3	
VENTILATION HOSE [CHARCOAL CANISTER], CHECK		AC117XCX	0.4	
ENGINE OIL, CHECK FOR LEAK		AC118XCX	0.3	
ENGINE OIL, CHANGE		AC118XRX	0.4	
ENGINE OIL PRESSURE, CHECK		AC119XCX	0.3	
COOLING SYSTEM, CHECK FOR LEAK		AC121XCX	0.2	
ENGINE COOLANT, CHANGE		AC122XRX	0.6	
FUEL PUMP FEEDING PRESSURE, CHECK		AC123XCX	0.4	
FUEL LINE AND CONNECTION, CHECK FOR LEAK		AC124XCX	0.3	
ACCELERATOR LINKAGE AND CHOKE MECHANISM, CHECK		AC125XCX	0.2	
FILLER CAP [FUEL TANK], CHECK		AC126XCX	0.2	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
BATTERY TERMINAL, CLEAN AND CHECK		AC130XCX	0.2	
IGNITION COIL [ALL], CHECK		AC132XCX	0.3	
LIGHT AND METER, CHECK		AC136XCX	0.2	
SEAT BELT WARNING SYSTEM, CHECK		AC138XCX	0.2	
SEAT BELT EMERGENCY LOCKING RETRACTOR, CHECK		AC139XCX	0.2	
CLIMATE MODE CONTROL, CHECK		AC140XCX	0.3	
AUTOMATIC TRANSMISSION FLUID LEVEL, CHECK AND ADJUST		AC147XAX	0.5	
REAR AXLE OIL, CHANGE		AC149XRX	0.3	
BRAKE FLUID LEVEL, CHECK		AC154XCX	0.2	
DISC BRAKE PAD [ALL], CHECK AND ADJUST	Front side	AC158AAX	0.5	
DISC BRAKE PAD [ALL], CHECK AND ADJUST	Rear side	AC158BAX	0.6	
DISC BRAKE PAD [ALL], CHECK AND ADJUST	All	AC158CAX	0.8	
BRAKE FLUID, CHANGE		AC160XRX	0.4	
AIR BLEED [BRAKE LINE], ALL WHEELS		AC161XRX	0.4	
WHEEL, INTERCHANGE		AC162XRX	0.7	◆Tire pressure, Adjust
PURGE SOLENOID VALVE, CHECK		AC176XCX	0.5	
RADIATOR FILLER CAP, CHECK		AC177XCX	0.2	
OXYGEN SENSOR, CHECK	SKYACTIV-G 2.5	AC178ACX	0.6	
OXYGEN SENSOR, CHECK	SKYACTIV-D 2.2	AC178XCX	0.4	
BOOST SENSOR, CHECK	SKYACTIV-G 2.5	AC182ACX	0.2	
BOOST SENSOR, CHECK	SKYACTIV-D 2.2	AC182XCX	0.3	
ENGINE COOLANT TEMPERATURE SENSOR/CYLINDER HEAD TEMPERATURE SENSOR, CHECK	SKYACTIV-G 2.5,Engine coolant temperature (ECT) sensor No.1	AC183ACX	0.8	◆Engine coolant temperature sensor (F0810), R&R
ENGINE COOLANT TEMPERATURE SENSOR/CYLINDER HEAD TEMPERATURE SENSOR, CHECK	SKYACTIV-G 2.5,Engine coolant temperature (ECT) sensor No.2	AC183BCX	1.3	◆Engine coolant temperature sensor (F0810), R&R

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
ENGINE COOLANT TEMPERATURE SENSOR/CYLINDER HEAD TEMPERATURE SENSOR, CHECK	SKYACTIV-D 2.2	AC183XCX	1.1	◆Engine coolant temperature sensor (F0810), R&R
IDLE SPEED & SMOKE, CHECK		AC185XCX	0.4	
VOLTAGE REGULATOR, CHECK		AC186XCX	0.4	
TIRE PRESSURE, CHECK AND ADJUST		AC189XAX	0.2	
WHEEL LUGNUT OR BOLT, CHECK AND RETIGHTEN		AC190XTX	0.2	
AUTOMATIC TRANSMISSION LINE PRESSURE, CHECK	SKYACTIV-G 2.5	AC191ACX	0.9	
AUTOMATIC TRANSMISSION LINE PRESSURE, CHECK	SKYACTIV-D 2.2	AC191XCX	0.8	
AUTOMATIC TRANSMISSION LINE PRESSURE & OPERATION, CHECK	SKYACTIV-G 2.5	AC193ACX	1.2	◆Stall test◆Time lag test◆Oil pressure test
AUTOMATIC TRANSMISSION LINE PRESSURE & OPERATION, CHECK	SKYACTIV-D 2.2	AC193XCX	1.1	◆Stall test◆Time lag test◆Oil pressure test
ATF, CHANGE		AC197XRX	0.6	
AC2 MAINTENANCE AND ADJUSTMENTS (NOT COVERED BY MANUFACTURER'S WARRANTY)				
FUEL INJECTOR INJECTION AMOUNT CORRECTION		AC204XAX	0.4	
AE2 MAINTENANCE SERVICE (For ADR) (NOT COVERED BY MANUFACTURER'S WARRANTY)				
MAINTENANCE SERVICE 1	SKYACTIV-D 2.2	AE201XMX	1.2	
MAINTENANCE SERVICE 1	SKYACTIV-G 2.5	AE201AMX	1.3	
MAINTENANCE SERVICE 2		AE202XMX	1.7	
MAINTENANCE SERVICE 3		AE203XMX	1.2	
MAINTENANCE SERVICE 4		AE204XMX	1.7	
MAINTENANCE SERVICE 5	SKYACTIV-D 2.2	AE205XMX	1.2	
MAINTENANCE SERVICE 5	SKYACTIV-G 2.5	AE205AMX	1.3	
MAINTENANCE SERVICE 6		AE206XMX	1.7	
MAINTENANCE SERVICE 7		AE207XMX	1.2	
MAINTENANCE SERVICE 8		AE208XMX	1.7	
MAINTENANCE SERVICE 9	SKYACTIV-D 2.2	AE209XMX	1.2	
MAINTENANCE SERVICE 9	SKYACTIV-G 2.5	AE209AMX	1.3	
MAINTENANCE SERVICE 10		AE210XMX	1.7	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
MAINTENANCE SERVICE 11		AE211XMX	1.2	
MAINTENANCE SERVICE 12		AE212XMX	1.7	
MAINTENANCE SERVICE 13	SKYACTIV-D 2.2	AE213XMX	1.2	
MAINTENANCE SERVICE 13	SKYACTIV-G 2.5	AE213AMX	1.3	
MAINTENANCE SERVICE 14		AE214XMX	1.7	
MAINTENANCE SERVICE 15		AE215XMX	1.2	
MAINTENANCE SERVICE 16		AE216XMX	1.7	
FUEL FILTER REPLACE	SKYACTIV-D 2.2	AE251XMX	1.0	
FUEL FILTER REPLACE	SKYACTIV-G 2.5	AE251AMX	1.1	
SPARK PLUGS REPLACE		AE252XMX	0.4	
AIR FILTER REPLACE		AE253XMX	0.2	
FUEL SYSTEM [DRAIN WATER]		AE254XMX	0.3	
ENGINE COOLANT REPLACE		AE255XMX	0.6	
BRAKE FLUID REPLACE		AE256XMX	0.4	
REAR DIFFERENTIAL OIL REPLACE		AE258XMX	0.3	
TRANSFER OIL REPLACE		AE259XMX	0.4	
CABIN AIR FILTER [IF EQUIPPED] REPLACE		AE260XMX	0.2	