

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
Z01 WIRE HARNESS				
FRONT HARNESS, R&R	SKYACTIV-G 2.5,RHD,Without 360°view monitor system	Z0101DRX	5.1	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-G 2.5,RHD,With 360°view monitor system,360°view monitor system screen display verification only	Z0101ERX	5.2	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-G 2.5,RHD,With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,Without rear console panel cup holder	Z0101FRX	5.3	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-G 2.5,RHD,With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,With rear console panel cup holder	Z0101KRX	5.4	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-D 2.2,Without 360°view monitor system,Without rear console panel cup holder	Z0101ARX	5.1	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-D 2.2,Without 360°view monitor system,With rear console panel cup holder	Z0101LRX	5.2	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-D 2.2,With 360°view monitor system,360°view monitor system screen display verification only	Z0101BRX	5.3	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-D 2.2,With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming	Z0101CRX	5.4	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	SKYACTIV-G 2.5,LHD,Without 360°view monitor system,Without rear console panel cup holder	Z0101GRX	3.4	◆Instrument panel assembly, R&R◆ Front bumper assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT HARNESS, R&R	<i>SKYACTIV-G 2.5,LHD,Without 360° view monitor system,With rear console panel cup holder</i>	<i>Z0101MRX</i>	<i>3.5</i>	◆ Instrument panel assembly, R&R ◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	<i>SKYACTIV-G 2.5,LHD,With 360°view monitor system,360°view monitor system screen display verification only,Without rear console panel cup holder</i>	Z0101HRX	3.5	◆ Instrument panel assembly, R&R ◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	<i>SKYACTIV-G 2.5,LHD,With 360°view monitor system,360°view monitor system screen display verification only,With rear console panel cup holder</i>	<i>Z0101NRX</i>	<i>3.6</i>	◆ Instrument panel assembly, R&R ◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	<i>SKYACTIV-G 2.5,LHD,With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,Without rear console panel cup holder</i>	Z0101JRX	3.6	◆ Instrument panel assembly, R&R ◆ Front bumper assembly, R&R
FRONT HARNESS, R&R	<i>SKYACTIV-G 2.5,LHD,With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,With rear console panel cup holder</i>	<i>Z0101PRX</i>	<i>3.7</i>	◆ Instrument panel assembly, R&R ◆ Front bumper assembly, R&R
INSTRUMENT PANEL HARNESS, R&R		Z0102XRX	3.2	◆ Instrument panel assembly, R&R
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM),SKYACTIV-G 2.5,2WD,Bench type second-row seat	Z0104JRX	8.2	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM),SKYACTIV-G 2.5,4WD,Bench type second-row seat	Z0104KRX	8.7	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-G 2.5, 2WD, Captain type second-row seat, With second-row seat console box	Z0104LRX	8.3	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-G 2.5, 4WD, Captain type second-row seat, With second-row seat console box	Z0104MRX	8.8	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM), SKYACTIV-G 2.5, 2WD, Captain type second-row seat, Without second-row seat console box, Without rear console panel cup holder</i>	Z0104NRX	8.2	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
<i>REAR HARNESS, R&R</i>	<i>Dashboard to rear body control module (RBCM), SKYACTIV-G 2.5, 2WD, Captain type second-row seat, Without second-row seat console box, With rear console panel cup holder</i>	<i>Z0104QRX</i>	<i>8.3</i>	<i>◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included</i>
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-G 2.5, 4WD, Captain type second-row seat, Without second-row seat console box	Z0104PRX	8.7	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 2WD, Bench type second-row seat	Z0104ARX	8.3	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 4WD, Bench type second-row seat	Z0104BRX	8.7	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 2WD, Captain type second-row seat, With second-row seat console box	Z0104ERX	8.4	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 4WD, Captain type second-row seat, With second-row seat console box	Z0104FRX	8.8	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 2WD, Captain type second-row seat, Without second-row seat console box, Without rear console panel cup holder</i>	Z0104GRX	8.3	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 2WD, Captain type second-row seat, Without second-row seat console box, With rear console panel cup holder</i>	Z0104RRX	8.4	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 4WD, Captain type second-row seat, Without second-row seat console box, Without rear console panel cup holder</i>	Z0104HRX	8.7	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM), SKYACTIV-D 2.2, 4WD, Captain type second-row seat, Without second-row seat console box, With rear console panel cup holder</i>	Z0104SRX	8.8	◆ Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness, Right side	Z0104CRX	2.7	
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness, Left side	Z0104DRX	1.1	
REAR HARNESS NO.2, R&R	Liftgate harness	Z0105XRX	0.6	◆ Liftgate trim (S1218), R&R
ENGINE HARNESS, R&R	Engine harness	Z0106XRX	0.6	
INTERIOR LAMP HARNESS, R&R		Z0107XRX	2.2	◆ Headliner (S1701), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT DOOR HARNESS, R&R	One side	Z0110ARX	0.5	◆Door trim (S1026), R&R
FRONT DOOR HARNESS, R&R	Both sides	Z0110BRX	0.7	◆Door trim (S1026), R&R
REAR DOOR HARNESS, R&R	One side	Z0111ARX	0.4	◆Door trim (S1125), R&R
REAR DOOR HARNESS, R&R	Both sides	Z0111BRX	0.6	◆Door trim (S1125), R&R
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	SKYACTIV-G 2.5	Z0112ARX	1.7	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	SKYACTIV-D 2.2	Z0112XRX	2.0	
EARTH WIRE [ENGINE TO BODY], R&R		Z0113XRX	0.2	