

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
D01 OIL PUMP & FILTER				
OIL PUMP ASSEMBLY AND/OR GASKET, R&R		D0101XRX	1.5	◆Oil pan and/or gasket (D0201), R&R
OIL FILTER CARTRIDGE, R&R		D0102XRX	0.3	
OIL COOLER AND/OR "O" RING, R&R	2WD,LHD	D0103ARX	2.9	◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter] ◆Front drive shaft (M0101), R&R [Right side]
OIL COOLER AND/OR "O" RING, R&R	2WD,RHD,Without i-stop	D0103BRX	3.7	◆Front crossmember assembly, R&R ◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter] ◆Front drive shaft (M0101), R&R [Right side]
OIL COOLER AND/OR "O" RING, R&R	2WD,RHD,With i-stop	D0103CRX	3.8	◆Front crossmember assembly, R&R ◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter] ◆Front drive shaft (M0101), R&R [Right side]
OIL COOLER AND/OR "O" RING, R&R	4WD,Without i-stop	D0103DRX	3.6	◆Front crossmember assembly, R&R ◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter] ◆Front drive shaft (M0101), R&R [Right side]

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OIL COOLER AND/OR "O" RING, R&R	4WD,With i-stop	D0103ERX	3.7	◆Front crossmember assembly, R&R◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter]◆Front drive shaft (M0101), R&R [Right side]
OIL STRAINER AND/OR GASKET, R&R	Without i-stop	D0104ARX	1.1	◆Oil pan and/or gasket (D0201), R&R
OIL STRAINER AND/OR GASKET, R&R	With i-stop	D0104BRX	1.2	◆Oil pan and/or gasket (D0201), R&R
ENGINE OIL SOLENOID VALVE, R&R	Without i-stop	D0110ARX	0.8	
ENGINE OIL SOLENOID VALVE, R&R	With i-stop	D0110BRX	0.9	
D02 OIL PAN				
OIL PAN AND/OR GASKET, R&R	Without i-stop	D0201ARX	1.1	
OIL PAN AND/OR GASKET, R&R	With i-stop	D0201BRX	1.2	
OIL PAN DRAIN PLUG AND/OR GASKET, R&R		D0202XRX	0.3	
OIL PAN BOLT [ALL], R&R	Without i-stop	D0203ARX	1.0	
OIL PAN BOLT [ALL], R&R	With i-stop	D0203BRX	1.1	
OIL FILLER CAP AND/OR GASKET, R&R		D0204XRX	0.2	
OIL LEVEL GAUGE, R&R		D0205XRX	0.2	
OIL JET AND/OR GASKET [ALL], R&R	2WD,Without i-stop,PCM cover with standard bolts,Without ATF oil cooler No.2	D0207FRX	12.7	◆Front crossmember assembly, R&R ◆Engine (B0101), R&R ◆Timing chain (B0210), R&R ◆Oil pan and/or gasket (D0201), R&R ◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	2WD,Without i-stop,PCM cover with standard bolts,With ATF oil cooler No.2	D0207ARX	12.8	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Timing chain (B0210), R&R◆Oil pan and/or gasket (D0201), R&R◆Crankshaft (B0502), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OIL JET AND/OR GASKET [ALL], R&R	[2WD,Without i-stop,PCM cover with shear-off bolts]/[2WD,With i-stop]	D0207BRX	12.9	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Timing chain (B0210), R&R◆Oil pan and/or gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	4WD,Without i-stop,PCM cover with standard bolts,Without ATF oil cooler No.2	D0207GRX	14.0	◆Front crossmember assembly, R&R ◆Propeller shaft assembly (L0101), R&R ◆ Engine (B0101), R&R ◆ Timing chain (B0210), R&R ◆ Oil pan and/or gasket (D0201), R&R ◆ Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	4WD,Without i-stop,PCM cover with standard bolts,With ATF oil cooler No.2	D0207CRX	14.1	◆Front crossmember assembly, R&R◆ Propeller shaft assembly (L0101), R&R◆ Engine (B0101), R&R◆Timing chain (B0210), R&R◆Oil pan and/or gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	[4WD,Without i-stop,PCM cover with shear-off bolts]/[4WD,With i-stop,Without i-ELOOP system]	D0207DRX	14.2	◆Front crossmember assembly, R&R◆ Propeller shaft assembly (L0101), R&R◆ Engine (B0101), R&R◆Timing chain (B0210), R&R◆Oil pan and/or gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	4WD,With i-stop,With i-ELOOP system	D0207ERX	14.3	◆Front crossmember assembly, R&R◆ Propeller shaft assembly (L0101), R&R◆ Engine (B0101), R&R◆Timing chain (B0210), R&R◆Oil pan and/or gasket (D0201), R&R◆Crankshaft (B0502), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
D03 OIL PIPE & HOSE				
OIL PIPE AND/OR GASKET [TURBOCHARGER TO OIL RETURN HOSE], R&R	2WD	D0302ARX	0.6	
OIL PIPE AND/OR GASKET [TURBOCHARGER TO OIL RETURN HOSE], R&R	4WD, Without i-stop	D0302BRX	2.9	◆Front crossmember assembly, R&R◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter]
OIL PIPE AND/OR GASKET [TURBOCHARGER TO OIL RETURN HOSE], R&R	4WD, With i-stop	D0302CRX	3.0	◆Front crossmember assembly, R&R◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter]
TURBOCHARGER INNER OIL PIPE, R&R	2WD	D0303ARX	0.5	
TURBOCHARGER INNER OIL PIPE, R&R	4WD, Without i-stop	D0303BRX	2.8	◆Front crossmember assembly, R&R◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter]
TURBOCHARGER INNER OIL PIPE, R&R	4WD, With i-stop	D0303CRX	2.9	◆Front crossmember assembly, R&R◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Warm up three way catalytic converter]