

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
Z01 WIRE HARNESS				
FRONT HARNESS, R&R	Without 360°view monitor system,LHD,PCM cover with standard bolts	Z0101ARX	3.3	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	Without 360°view monitor system,LHD,PCM cover with shear-off bolts	Z0101BRX	3.5	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	Without 360°view monitor system,RHD,Without i-stop	Z0101CRX	3.2	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	Without 360°view monitor system,RHD,With i-stop,Without i-ELOOP system	Z0101NRX	3.2	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	Without 360°view monitor system,RHD,With i-stop,With i-ELOOP system	Z0101DRX	3.3	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,LHD,PCM cover with standard bolts,Without i-stop	Z0101ERX	3.4	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,LHD,PCM cover with standard bolts,With i-stop	Z0101PRX	3.5	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,LHD,PCM cover with shear-off bolts	Z0101FRX	3.6	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,RHD,Without i-stop	Z0101GRX	3.3	◆Instrument panel assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,RHD,With i-stop,Without i-ELOOP system	Z0101QRX	3.4	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification only,RHD,With i-stop,With i-ELOOP system	Z0101HRX	3.5	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,LHD,PCM cover with standard bolts,Without i-stop	Z0101JRX	3.5	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,LHD,PCM cover with standard bolts,With i-stop	Z0101RRX	3.6	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,LHD,PCM cover with shear-off bolts	Z0101KRX	3.7	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,RHD,Without i-stop	Z0101LRX	3.4	◆Instrument panel assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,RHD,With i-stop,Without i-ELOOP system	Z0101SRX	3.4	◆Instrument panel assembly, R&R
FRONT HARNESS, R&R	With 360°view monitor system,360°view monitor system screen display verification and 360°view monitor system aiming,RHD,With i-stop,With i-ELOOP system	Z0101MRX	3.5	◆Instrument panel assembly, R&R
INSTRUMENT PANEL HARNESS, R&R	Without i-stop	Z0102ARX	3.2	◆Instrument panel assembly, R&R
INSTRUMENT PANEL HARNESS, R&R	With i-stop	Z0102BRX	3.3	◆Instrument panel assembly, R&R
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM),Without surface fastener,Without i-stop	Z0104ARX	9.0	◆Instrument panel assembly, R&R
REAR HARNESS, R&R	Dashboard to rear body control module (RBCM),Without surface fastener,With i-stop	Z0104KRX	9.1	◆Instrument panel assembly, R&R
REAR HARNESS, R&R	<i>Dashboard to rear body control module (RBCM),With surface fastener,Bench type second-row seat</i>	Z0104LRX	9.1	◆Instrument panel assembly, R&R
<i>REAR HARNESS, R&R</i>	<i>Dashboard to rear body control module (RBCM),With surface fastener,Captain type second-row seat</i>	<i>Z0104MRX</i>	<i>9.2</i>	<i>◆Instrument panel assembly, R&R</i>
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Right side,Without rear fog light,Without i-stop	Z0104BRX	1.2	◆Rear bumper assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Right side,Without rear fog light,With i-stop	Z0104CRX	1.3	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Right side,With rear fog light,Without i-stop	Z0104DRX	1.2	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Right side,With rear fog light,With i-stop	Z0104ERX	1.3	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Left side,Without rear fog light,Without i-stop	Z0104FRX	1.0	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Left side,Without rear fog light,With i-stop	Z0104GRX	1.1	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Left side,With rear fog light,Without i-stop	Z0104HRX	1.0	◆Rear bumper assembly, R&R
REAR HARNESS, R&R	Blind spot monitoring (BSM) control module harness,Left side,With rear fog light,With i-stop	Z0104JRX	1.1	◆Rear bumper assembly, R&R
REAR HARNESS NO.2, R&R	Liftgate harness,Without i-stop	Z0105ARX	0.6	
REAR HARNESS NO.2, R&R	Liftgate harness,With i-stop	Z0105BRX	0.7	
ENGINE HARNESS, R&R	Capacitor harness,Generator to capacitor	Z0106XRX	0.6	
INTERIOR LAMP HARNESS, R&R		Z0107XRX	1.8	◆Headliner (S1701), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT DOOR HARNESS, R&R	One side,Without i-stop	Z0110ARX	0.4	◆Door trim (S1026), R&R
FRONT DOOR HARNESS, R&R	One side,With i-stop	Z0110BRX	0.5	◆Door trim (S1026), R&R
FRONT DOOR HARNESS, R&R	Both sides	Z0110CRX	0.7	◆Door trim (S1026), R&R
REAR DOOR HARNESS, R&R	One side	Z0111ARX	0.4	◆Door trim (S1125), R&R
REAR DOOR HARNESS, R&R	Both sides,Without i-stop	Z0111BRX	0.6	◆Door trim (S1125), R&R
REAR DOOR HARNESS, R&R	Both sides,With i-stop	Z0111CRX	0.7	◆Door trim (S1125), R&R
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	Turbocharger side,Without i-stop	Z0112ARX	0.8	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	Turbocharger side,With i-stop,Without i-ELOOP system	Z0112GRX	0.8	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	Turbocharger side,With i-stop,With i-ELOOP system	Z0112BRX	0.9	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	[PCM side,2WD,Without i-stop,PCM cover with standard bolts]/[PCM side,2WD,With i-stop,Without i-ELOOP system]	Z0112CRX	3.6	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	[PCM side,2WD,Without i-stop,PCM cover with shear-off bolts]/[PCM side,2WD,With i-stop,With i-ELOOP system]	Z0112DRX	3.7	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	PCM side,4WD,Without i-stop,PCM cover with standard bolts	Z0112ERX	3.7	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	PCM side,4WD,With i-stop,Without i-ELOOP system	Z0112HRX	3.8	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	[PCM side,4WD,Without i-stop,PCM cover with shear-off bolts]/[PCM side,4WD,With i-stop,With i-ELOOP system]	Z0112FRX	3.9	
EARTH WIRE [ENGINE TO BODY], R&R		Z0113XRX	0.2	
BATTERY CABLE [POSITIVE], R&R	Capacitor harness,Capacitor to DC-DC converter	Z0117XRX	0.5	