

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
P00 DIAGNOSIS									
DTC READING BY DIAGNOSTIC TOOL The labor operation for DIAGNOSTIC TOOLS usage (P9999*-*~*) can be applied only when the diagnosis requires the NGS/WDS/PDS/IDS tester to read the Diagnostic Trouble Code for ABS components.							P9999XDX	0.2	
P01 FRONT BRAKE									
CALIPER ASSEMBLY, OH	Both sides						P0101AHX	1.0	◆ Caliper assembly (P0101), R&R◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, OH	One side						P0101BHX	0.7	◆ Caliper assembly (P0101), R&R◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Both sides						P0101ARX	0.7	◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	One side						P0101BRX	0.6	◆ Brake line (A0120), Air bleed
DISC PLATE, R&R	Both sides						P0102ARX	0.5	◆ Caliper assembly (P0101), D&C
DISC PLATE, R&R	One side						P0102BRX	0.4	◆ Caliper assembly (P0101), D&C
DUST PLATE, R&R	Both sides						P0103ARX	0.8	◆ Caliper assembly (P0101), D&C◆ Front wheel hub (M0203), R&R
DUST PLATE, R&R	One side						P0103BRX	0.5	◆ Caliper assembly (P0101), D&C◆ Front wheel hub (M0203), R&R
PAD, R&R	Both sides						P0104ARX	0.4	◆ Caliper assembly (P0101), D&C
PAD, R&R	One side						P0104BRX	0.3	◆ Caliper assembly (P0101), D&C
PAD ATTACHMENT, R&R	Both sides						P0105ARX	0.4	◆ Pad (P0104), R&R◆ Caliper assembly (P0101), D&C
PAD ATTACHMENT, R&R	One side						P0105BRX	0.3	◆ Pad (P0104), R&R◆ Caliper assembly (P0101), D&C
SEAL KIT, R&R	Both sides						P0106ARX	0.8	◆ Caliper assembly (P0101), R&R◆ Brake line (A0120), Air bleed
SEAL KIT, R&R	One side						P0106BRX	0.6	◆ Caliper assembly (P0101), R&R◆ Brake line (A0120), Air bleed
DISC PLATE, MACHINE	Both sides						P0113AMX	Max 1.0	◆ Caliper assembly (P0101), D&C
DISC PLATE, MACHINE	One side						P0113BMX	Max 0.6	◆ Caliper assembly (P0101), D&C
P02 REAR BRAKE									
CALIPER ASSEMBLY, OH	Both sides						P0207AHX	1.0	◆ Caliper assembly (P0207), R&R◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, OH	One side						P0207BHX	0.7	◆ Caliper assembly (P0207), R&R◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	Both sides						P0207ARX	0.8	◆ Brake line (A0120), Air bleed
CALIPER ASSEMBLY, R&R	One side						P0207BRX	0.6	◆ Brake line (A0120), Air bleed
DISC PLATE, R&R	Both sides						P0208ARX	0.7	◆ Caliper assembly (P0207), D&C
DISC PLATE, R&R	One side						P0208BRX	0.5	◆ Caliper assembly (P0207), D&C
PAD, R&R	Both sides						P0209ARX	0.4	◆ Caliper assembly (P0207), D&C
PAD, R&R	One side						P0209BRX	0.3	◆ Caliper assembly (P0207), D&C
BACK PLATE, R&R	Both sides						P0212ARX	0.8	◆ Rear wheel hub (M0314), R&R
BACK PLATE, R&R	One side						P0212BRX	0.5	◆ Rear wheel hub (M0314), R&R
DISC PLATE, MACHINE	Both sides						P0214AMX	Max 1.2	◆ Caliper assembly (P0207), D&C
DISC PLATE, MACHINE	One side						P0214BMX	Max 0.8	◆ Caliper assembly (P0207), D&C
P03 BRAKE PEDAL									
BRAKE PEDAL AND/OR BUSH, R&R	LHD						P0301ARX	1.3	
BRAKE PEDAL AND/OR BUSH, R&R	RHD						P0301BRX	0.9	
BRAKE SWITCH, R&R							P0302ARX	0.2	

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
P04 POWER BRAKE & BRAKE PIPING									
FRONT BRAKE HOSE, R&R	Both sides						P0408ARX	0.6	◆ Brake line (A0120), Air bleed
FRONT BRAKE HOSE, R&R	One side						P0408BRX	0.5	◆ Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	Both sides						P0409ARX	0.6	◆ Brake line (A0120), Air bleed
REAR BRAKE HOSE, R&R	One side						P0409BRX	0.5	◆ Brake line (A0120), Air bleed
SKID CONTROL CM, BRAKE BOOSTER ASSEMBLY, R&R	Electronically controlled brake unit	LHD					P0411ARX	1.5	◆ Brake line (A0120), Air bleed
SKID CONTROL CM, BRAKE BOOSTER ASSEMBLY, R&R	Electronically controlled brake unit	RHD					P0411BRX	1.4	◆ Brake line (A0120), Air bleed
P05 ANTILOCK BRAKE SYSTEM									
ABS FRONT SENSOR, R&R	Both sides						P0501ARX	0.4	
ABS FRONT SENSOR, R&R	One side						P0501BRX	0.3	
ABS REAR SENSOR, R&R	Both sides						P0504ARX	1.1	◆ Trunk side trim (S1707), D&C
ABS REAR SENSOR, R&R	One side						P0504BRX	0.7	◆ Trunk side trim (S1707), D&C
P06 PARKING BRAKE									
ELECTRIC PARKING BRAKE ACTUATOR, R&R	Both sides						P0608ARX	0.4	
ELECTRIC PARKING BRAKE ACTUATOR, R&R	One side						P0608BRX	0.3	
ELECTRIC PARKING BRAKE SWITCH, R&R							P0610ARX	0.3	