

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
S01 LOCK SET									
DOOR LOCK SUB SET, R&R							S0102ARX	0.8	
S02 BUMPER									
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S0201ARX	1.5	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system	With ultrasonic sensor		S0201BRX	1.5	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system	Without ultrasonic sensor		S0201CRX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system	With ultrasonic sensor		S0201DRX	1.5	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system	Without ultrasonic sensor		S0201ERX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system			S0201FRX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	Without 360°view monitor system	With front cross traffic alert (FCTA) system				S0201GRX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	Without 360°view monitor system	Without front cross traffic alert (FCTA) system	With ultrasonic sensor			S0201HRX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper face	Without 360°view monitor system	Without front cross traffic alert (FCTA) system	Without ultrasonic sensor			S0201JRX	1.3	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper reinforcement	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S0201KRX	1.9	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper reinforcement	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system			S0201LRX	1.9	◆Radar sensor aiming

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT BUMPER, R&R	Front bumper reinforcement	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system			S0201MRX	1.8	◆Radar sensor aiming
FRONT BUMPER, R&R	Front bumper reinforcement	Without 360°view monitor system					S0201NRX	1.8	◆Radar sensor aiming
FRONT BUMPER, R&R	Upper face	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S0201PRX	1.4	◆Radar sensor aiming
FRONT BUMPER, R&R	Upper face	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system			S0201QRX	1.3	◆Radar sensor aiming
FRONT BUMPER, R&R	Upper face	With 360°view monitor system	360°view monitor system screen display verification only				S0201RRX	1.3	◆Radar sensor aiming
FRONT BUMPER, R&R	Upper face	Without 360°view monitor system	With front cross traffic alert (FCTA) system				S0201SRX	1.3	◆Radar sensor aiming
FRONT BUMPER, R&R	Upper face	Without 360°view monitor system	Without front cross traffic alert (FCTA) system				S0201TRX	1.2	◆Radar sensor aiming
RADIATOR GRILLE, R&R	Radiator grille assembly	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S0204ARX	1.2	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille assembly	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system			S0204BRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille assembly	With 360°view monitor system	360°view monitor system screen display verification only				S0204CRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille assembly	Without 360°view monitor system	With front cross traffic alert (FCTA) system				S0204DRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille assembly	Without 360°view monitor system	Without front cross traffic alert (FCTA) system				S0204ERX	1.0	◆Front bumper assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
RADIATOR GRILLE, R&R	Radiator grille only	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S0204FRX	1.2	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille only	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system			S0204GRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille only	With 360°view monitor system	360°view monitor system screen display verification only				S0204HRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille only	Without 360°view monitor system	With front cross traffic alert (FCTA) system				S0204JRX	1.1	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	Radiator grille only	Without 360°view monitor system	Without front cross traffic alert (FCTA) system				S0204KRX	1.0	◆Front bumper assembly, R&R
REAR BUMPER, R&R	Rear bumper face						S0206ARX	1.6	◆Radar sensor aiming
REAR BUMPER, R&R	Rear bumper reinforcement						S0206BRX	1.3	◆Radar sensor aiming
S04 MOLDINGS & PROTECTORS									
FRONT WINDOW MOLDINGS, R&R							S0401ARX	3.2	◆Windshield glass (S1401), R&R◆Water leak, Check◆Forward sensing camera [FSC], Aiming
FRONT BELT LINE MOLDING, R&R	One or both sides						S0405ARX	0.2	
COWL GRILLE, R&R							S0412ARX	0.3	
REAR PILLAR GARNISH, R&R	One or both sides						S0413ARX	0.2	
REAR FINISHER, R&R	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming					S0414ARX	0.8	◆Liftgate trim (S1218), R&R
REAR FINISHER, R&R	With 360°view monitor system	360°view monitor system screen display verification only					S0414BRX	0.8	◆Liftgate trim (S1218), R&R
REAR FINISHER, R&R	Without 360°view monitor system	With advanced keyless entry system					S0414CRX	0.7	◆Liftgate trim (S1218), R&R
REAR FINISHER, R&R	Without 360°view monitor system	Without advanced keyless entry system					S0414DRX	0.6	◆Liftgate trim (S1218), R&R
EXTRACTOR CHAMBER, R&R	Both sides						S0416ARX	1.2	◆Rear bumper assembly, R&R
EXTRACTOR CHAMBER, R&R	One side						S0416BRX	1.2	◆Rear bumper assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
ORNAMENT [REAR], R&R							S0417ARX	0.2	
ORNAMENT [GRILLE], R&R							S0419ARX	0.2	
FRONT DOOR MOLDING, R&R	Front door garnish	Both sides					S0423ARX	0.5	◆Front belt line molding (S0405), R&R
FRONT DOOR MOLDING, R&R	Front door garnish	One side					S0423BRX	0.3	◆Front belt line molding (S0405), R&R
REAR DOOR MOLDING, R&R	Rear door garnish	Both sides					S0424ARX	0.4	
REAR DOOR MOLDING, R&R	Rear door garnish	One side					S0424BRX	0.3	
REAR DOOR MOLDING, R&R	Rear sash molding	Both sides					S0424CRX	0.6	
REAR DOOR MOLDING, R&R	Rear sash molding	One side					S0424DRX	0.4	
ROOF MOLDING, R&R	One or both sides						S0431ARX	0.2	
<b>S05 BONNET (HOOD) &amp; TRUNK LID</b>									
BONNET [HOOD], R&R							S0503ARX	0.5	◆Bonnet, Adjust
BONNET [HOOD] HINGE, R&R	Both sides						S0504ARX	0.5	◆Bonnet, Adjust
BONNET [HOOD] HINGE, R&R	One side						S0504BRX	0.4	◆Bonnet, Adjust
BONNET [HOOD] LOCK, R&R							S0508ARX	0.3	
BONNET [HOOD] LOCK RELEASE WIRE, R&R	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming					S0509ARX	1.3	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system				S0509BRX	1.3	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system				S0509CRX	1.2	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	Without 360°view monitor system						S0509DRX	1.2	◆Front bumper assembly, R&R
BONNET [HOOD] CUSHION RUBBER [ONE OR ALL], R&R							S0510ARX	0.2	
ENGINE ROOM WEATHERSTRIP [ONE OR ALL], R&R							S0518ARX	0.2	
BONNET [HOOD] INSULATOR, R&R							S0519ARX	0.2	
<b>S06 BODY PANEL &amp; FLOOR ATTACHMENT</b>									
FRONT FENDER, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S0601ARX	3.3	◆Front bumper assembly, R&R
FRONT FENDER, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification only				S0601BRX	3.0	◆Front bumper assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT FENDER, R&R	Both sides	Without 360°view monitor system					S0601CRX	2.9	◆Front bumper assembly, R&R
FRONT FENDER, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S0601DRX	2.1	◆Front bumper assembly, R&R
FRONT FENDER, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system			S0601ERX	2.0	◆Front bumper assembly, R&R
FRONT FENDER, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system			S0601FRX	1.9	◆Front bumper assembly, R&R
FRONT FENDER, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system			S0601GRX	1.8	◆Front bumper assembly, R&R
FRONT FENDER, R&R	One side	Without 360°view monitor system					S0601HRX	1.8	◆Front bumper assembly, R&R
FRONT MUD GUARD, R&R	Both sides						S0603ARX	0.6	
FRONT MUD GUARD, R&R	One side						S0603BRX	0.4	
UNDER COVER, R&R							S0604ARX	0.3	
REAR MUD GUARD, R&R	Both sides						S0610ARX	0.4	
REAR MUD GUARD, R&R	One side						S0610BRX	0.3	
SHROUD PANEL, R&R	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming					S0612ARX	2.6	◆Front bumper assembly, R&R
SHROUD PANEL, R&R	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system				S0612BRX	2.6	◆Front bumper assembly, R&R
SHROUD PANEL, R&R	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system				S0612CRX	2.5	◆Front bumper assembly, R&R
SHROUD PANEL, R&R	Without 360°view monitor system						S0612DRX	2.5	◆Front bumper assembly, R&R
OVER FENDER, R&R	Front over fender	Both sides					S0613ARX	0.3	
OVER FENDER, R&R	Front over fender	One side					S0613BRX	0.2	
OVER FENDER, R&R	Front side garnish	Both sides					S0613CRX	0.4	

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OVER FENDER, R&R	Front side garnish	One side					S0613DRX	0.3	
OVER FENDER, R&R	Rear over fender	Both sides					S0613ERX	0.2	
OVER FENDER, R&R	Rear over fender	One side					S0613FRX	0.2	
OVER FENDER, R&R	Rear side garnish	Both sides					S0613GRX	0.4	
OVER FENDER, R&R	Rear side garnish	One side					S0613HRX	0.3	
<b>S07 INSTRUMENT PANEL</b>									
STEERING COLUMN COVER, R&R	Lower						S0706ARX	0.9	
STEERING COLUMN COVER, R&R	Upper						S0706BRX	0.9	
CRUSH PAD, R&R							S0708ARX	3.2	◆Instrument panel assembly, R&R
INSTRUMENT PANEL FRAME, R&R							S0709ARX	3.3	◆Instrument panel assembly, R&R
LOWER PANEL, R&R	Center						S0710ARX	0.8	◆Rear console (S0803), R&R
LOWER PANEL, R&R	Driver side						S0710BRX	0.5	
LOWER PANEL, R&R	Passenger side						S0710CRX	0.5	
GLOVE BOX ASSEMBLY, R&R							S0716ARX	0.2	
UNDER COVER, R&R							S0717ARX	0.2	
<b>S08 CONSOLE</b>									
FRONT CONSOLE, R&R							S0802ARX	0.6	
REAR CONSOLE, R&R							S0803ARX	0.4	
CONSOLE BOX, R&R	Front console box						S0804ARX	0.6	
<b>S09 SEATS &amp; SEAT BELTS</b>									
FRONT SEAT ASSEMBLY, R&R	Both sides						S0901ARX	0.5	
FRONT SEAT ASSEMBLY, R&R	Driver side	With power seat					S0901BRX	0.4	
FRONT SEAT ASSEMBLY, R&R	Driver side	Without power seat					S0901CRX	0.3	
FRONT SEAT ASSEMBLY, R&R	Passenger side						S0901DRX	0.3	
FRONT SEAT CUSHION, R&R	Both sides						S0902ARX	1.7	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Driver side	With power seat	With seat warmer				S0902BRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Driver side	With power seat	Without seat warmer				S0902CRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Driver side	Without power seat					S0902DRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Passenger side						S0902ERX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Both sides						S0903ARX	1.7	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Driver side	With power seat					S0903BRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Driver side	Without power seat					S0903CRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Passenger side						S0903DRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Both sides						S0904ARX	1.9	◆Front seat assembly (S0901), R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT BACK, R&R	Driver side	With walk in switch					S0904BRX	1.1	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Driver side	Without walk in switch					S0904CRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Passenger side						S0904DRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Both sides						S0905ARX	1.9	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Driver side	With walk in switch					S0905BRX	1.1	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Driver side	Without walk in switch					S0905CRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Passenger side						S0905DRX	1.0	◆Front seat assembly (S0901), R&R
REAR SEAT CUSHION, R&R							S0906ARX	0.2	
REAR SEAT CUSHION TRIM, R&R							S0907ARX	1.5	◆Rear seat cushion (S0906), R&R
REAR SEAT BACK, R&R	Both sides						S0908ARX	0.4	
REAR SEAT BACK, R&R	Left side						S0908BRX	0.4	
REAR SEAT BACK, R&R	Right side						S0908CRX	0.2	
REAR SEAT BACK TRIM, R&R	Both sides						S0909ARX	1.3	◆Rear seat back (S0908), R&R
REAR SEAT BACK TRIM, R&R	Left side						S0909BRX	0.8	◆Rear seat back (S0908), R&R
REAR SEAT BACK TRIM, R&R	Right side						S0909CRX	0.6	◆Rear seat back (S0908), R&R
FRONT HEADREST, R&R	One or both sides						S0910ARX	0.2	
FRONT SEAT ADJUSTER, R&R	Both sides						S0913ARX	1.5	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Driver side						S0913BRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Passenger side						S0913CRX	0.8	◆Front seat assembly (S0901), R&R
LIFTER LEVER, R&R							S0915ARX	0.2	
REAR SEAT HINGE, R&R	Center						S0916ARX	0.4	◆Rear seat cushion (S0906), R&R◆ Rear seat back (S0908), R&R
REAR SEAT HINGE, R&R	Side	Both sides					S0916BRX	0.6	◆Rear seat cushion (S0906), R&R◆ Rear seat back (S0908), R&R
REAR SEAT HINGE, R&R	Side	Left side					S0916CRX	0.4	◆Rear seat cushion (S0906), R&R◆ Rear seat back (S0908), R&R
REAR SEAT HINGE, R&R	Side	Right side					S0916DRX	0.4	◆Rear seat cushion (S0906), R&R◆ Rear seat back (S0908), R&R
SEAT WARMER, R&R	Seat back side	Both sides					S0918ARX	1.9	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back side	Driver side	With walk in switch				S0918BRX	1.1	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back side	Driver side	Without walk in switch				S0918CRX	1.0	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back side	Passenger side					S0918DRX	1.1	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion side	Both sides	With power seat				S0918ERX	1.7	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion side	Both sides	Without power seat				S0918FRX	1.8	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion side	Driver side					S0918GRX	1.0	◆Front seat assembly (S0901), R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SEAT WARMER, R&R	Seat cushion side	Passenger side					S0918HRX	1.0	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat warmer control unit						S0918JRX	0.4	
FRONT SEAT BELT [RETRACTOR], R&R	Both sides						S0919ARX	0.7	
FRONT SEAT BELT [RETRACTOR], R&R	One side						S0919BRX	0.5	
REAR SEAT BELT, R&R	Buckle	All					S0920ARX	0.4	◆Rear seat cushion (S0906), R&R
REAR SEAT BELT, R&R	Buckle	One					S0920BRX	0.3	◆Rear seat cushion (S0906), R&R
REAR SEAT BELT, R&R	Retractor	Center					S0920CRX	0.7	◆Rear seat back (S0908), R&R
REAR SEAT BELT, R&R	Retractor	Side	Both sides				S0920DRX	0.5	◆"B" pillar trim (S1703), R&R
REAR SEAT BELT, R&R	Retractor	Side	One side				S0920ERX	0.4	◆"B" pillar trim (S1703), R&R
FRONT SEAT SIDE PANEL, R&R	Both sides	With power seat					S0927ARX	0.5	
FRONT SEAT SIDE PANEL, R&R	Both sides	Without power seat					S0927BRX	0.4	
FRONT SEAT SIDE PANEL, R&R	One side	With power seat					S0927CRX	0.4	
FRONT SEAT SIDE PANEL, R&R	One side	Without power seat					S0927DRX	0.3	
FRONT SEAT FRAME, R&R	Seat back frame	Both sides	With power seat				S0928ARX	2.0	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Both sides	Without power seat	With seat warmer			S0928BRX	1.9	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Both sides	Without power seat	Without seat warmer			S0928CRX	1.8	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Driver side	With power seat				S0928DRX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Driver side	Without power seat	With seat warmer			S0928ERX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Driver side	Without power seat	Without seat warmer			S0928FRX	1.1	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame	Passenger side					S0928GRX	1.0	◆Front seat assembly (S0901), R&R
SEAT LOCK, R&R	Both sides	With arm rest					S0929ARX	0.9	◆Rear seat back (S0908), R&R
SEAT LOCK, R&R	Both sides	Without arm rest					S0929BRX	0.8	◆Rear seat back (S0908), R&R
SEAT LOCK, R&R	Left side	With arm rest					S0929CRX	0.7	◆Rear seat back (S0908), R&R
SEAT LOCK, R&R	Left side	Without arm rest					S0929DRX	0.6	◆Rear seat back (S0908), R&R
SEAT LOCK, R&R	Right side						S0929ERX	0.4	◆Rear seat back (S0908), R&R
ARM REST TRIM AND/OR PAD, R&R							S0931ARX	0.6	
REAR SEAT BACK FRAME, R&R	Both sides	With arm rest					S0939ARX	0.9	◆Rear seat back (S0908), R&R
REAR SEAT BACK FRAME, R&R	Both sides	Without arm rest					S0939BRX	0.8	◆Rear seat back (S0908), R&R
REAR SEAT BACK FRAME, R&R	Left side	With arm rest					S0939CRX	0.7	◆Rear seat back (S0908), R&R
REAR SEAT BACK FRAME, R&R	Left side	Without arm rest					S0939DRX	0.6	◆Rear seat back (S0908), R&R
REAR SEAT BACK FRAME, R&R	Right side						S0939ERX	0.5	◆Rear seat back (S0908), R&R
REAR HEADREST, R&R	One or all						S0940ARX	0.2	



OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
POWER SEAT MOTOR SWITCH, R&R	Power seat switch						S0942ARX	0.4	
POWER SEAT MOTOR SWITCH, R&R	Walk in switch						S0942BRX	0.8	
FRONT SEAT BELT [BUCKLE], R&R	Both sides						S0944ARX	0.6	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	One side						S0944BRX	0.4	◆Front seat assembly (S0901), R&R
S10 FRONT DOORS									
DOOR BODY, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1001ARX	3.9	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification only				S1001BRX	3.6	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Both sides	Without 360°view monitor system					S1001CRX	3.4	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Left side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1001DRX	2.1	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Left side	With 360°view monitor system	360°view monitor system screen display verification only				S1001ERX	1.9	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Left side	Without 360°view monitor system					S1001FRX	1.8	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Right side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1001GRX	2.2	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Right side	With 360°view monitor system	360°view monitor system screen display verification only				S1001HRX	2.0	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Right side	Without 360°view monitor system					S1001JRX	1.8	◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1002ARX	3.5	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
DOOR HINGE, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification only				S1002BRX	3.2	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	Both sides	Without 360°view monitor system					S1002CRX	3.1	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1002DRX	2.2	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification only				S1002ERX	2.0	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	One side	Without 360°view monitor system					S1002FRX	1.9	◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
GLASS & GLASS HOLDER, R&R	Both sides						S1003ARX	0.9	◆Door trim assembly, R&R
GLASS & GLASS HOLDER, R&R	One side						S1003BRX	0.5	◆Door trim assembly, R&R
GLASS RUN CHANNEL, R&R	Both sides						S1005ARX	1.4	◆Door trim assembly, R&R
GLASS RUN CHANNEL, R&R	One side						S1005BRX	0.8	◆Door trim assembly, R&R
DOOR CHECKER, R&R	Both sides						S1006ARX	0.8	◆Door trim assembly, R&R
DOOR CHECKER, R&R	One side						S1006BRX	0.5	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	Both sides						S1007ARX	0.7	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	One side						S1007BRX	0.4	◆Door trim assembly, R&R
DOOR LOCK SWITCH, R&R	Driver side						S1008ARX	0.4	◆Door trim assembly, R&R
DOOR LOCK SWITCH, R&R	Liftgate side						S1008BRX	0.3	◆Door trim assembly, R&R
INNER HANDLE, R&R	Both sides						S1009ARX	0.6	◆Door trim assembly, R&R
INNER HANDLE, R&R	One side						S1009BRX	0.4	◆Door trim assembly, R&R
INNER HANDLE COVER, R&R	One or both sides						S1010ARX	0.2	
OUTER HANDLE, R&R	Handle	Both sides					S1013ARX	0.7	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle	Left side					S1013BRX	0.4	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle	Right side					S1013CRX	0.5	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle bracket	Both sides					S1013DRX	0.8	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle bracket	One side					S1013ERX	0.5	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Motor	Both sides					S1015ARX	1.0	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Motor	One side					S1015BRX	0.6	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Regulator	Both sides					S1015CRX	1.1	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Regulator	One side					S1015DRX	0.6	◆Door trim assembly, R&R
SEAMING WELT, R&R	Both sides						S1020ARX	0.3	
SEAMING WELT, R&R	One side						S1020BRX	0.2	
DOOR WEATHERSTRIP, R&R	Both sides						S1021ARX	0.6	◆Water leak, Check
DOOR WEATHERSTRIP, R&R	One side						S1021BRX	0.4	◆Water leak, Check
INNER WEATHERSTRIP, R&R	Both sides						S1023ARX	0.5	◆Door trim assembly, R&R
INNER WEATHERSTRIP, R&R	One side						S1023BRX	0.4	◆Door trim assembly, R&R
DOOR TRIM, R&R	Both sides						S1026ARX	0.6	

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
DOOR TRIM, R&R	One side						S1026BRX	0.4	
DOOR STRIKER, R&R	Both sides						S1032ARX	0.3	
DOOR STRIKER, R&R	One side						S1032BRX	0.2	
KEYLESS TRANSMITTER BATTERY, R&R							S1038ARX	0.2	
KEYLESS RECEIVER, R&R							S1041ARX	0.3	
KEYLESS TRANSMITTER, R&R							S1042ARX	0.2	
KEYLESS ANTENNA [FRONT DOOR], R&R	Both sides						S1044ARX	0.7	◆Door trim assembly, R&R
KEYLESS ANTENNA [FRONT DOOR], R&R	Left side						S1044BRX	0.4	◆Door trim assembly, R&R
KEYLESS ANTENNA [FRONT DOOR], R&R	Right side						S1044CRX	0.5	◆Door trim assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, FRONT], R&R							S1045ARX	0.3	
KEYLESS ANTENNA [VEHICLE INTERIOR, REAR], R&R							S1047ARX	0.3	
KEYLESS ANTENNA [VEHICLE EXTERIOR, REAR], R&R							S1048ARX	0.4	
REQUEST SWITCH [FRONT DOOR], R&R	Both sides						S1050ARX	0.7	◆Door trim assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	Left side						S1050BRX	0.4	◆Door trim assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	Right side						S1050CRX	0.5	◆Door trim assembly, R&R
REQUEST SWITCH OR OPENER SWITCH [LIFTGATE], R&R	Opener switch	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1052ARX	0.8	◆Liftgate trim (S1218), R&R [Lower]
REQUEST SWITCH OR OPENER SWITCH [LIFTGATE], R&R	Opener switch	With 360°view monitor system	360°view monitor system screen display verification only				S1052BRX	0.7	◆Liftgate trim (S1218), R&R [Lower]
REQUEST SWITCH OR OPENER SWITCH [LIFTGATE], R&R	Opener switch	Without 360°view monitor system					S1052CRX	0.6	◆Liftgate trim (S1218), R&R [Lower]
KEYLESS BEEPER, R&R							S1053ARX	0.4	◆Cowl grille (S0412), R&R
LF CONTROL UNIT, R&R							S1055ARX	0.4	
S11 REAR DOORS									
DOOR BODY, R&R	Both sides						S1101ARX	6.1	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	One side						S1101BRX	3.2	◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	Both sides						S1102ARX	1.3	◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	One side						S1102BRX	0.8	◆Door, Adjust◆Water leak, Check
GLASS & GLASS HOLDER, R&R	Both sides						S1103ARX	4.2	◆Door trim assembly, R&R
GLASS & GLASS HOLDER, R&R	One side						S1103BRX	2.2	◆Door trim assembly, R&R
DOOR CHECKER, R&R	Both sides						S1107ARX	0.6	◆Door trim assembly, R&R
DOOR CHECKER, R&R	One side						S1107BRX	0.4	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	Lower	Both sides					S1108ARX	1.1	◆Door trim assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
DOOR LOCK ASSEMBLY, R&R	Lower	One side					S1108BRX	0.6	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	Upper	Both sides					S1108CRX	0.8	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	Upper	One side					S1108DRX	0.5	◆Door trim assembly, R&R
INNER HANDLE, R&R	Rear door release handle	Both sides					S1109ARX	0.5	◆Door trim assembly, R&R
INNER HANDLE, R&R	Rear door release handle	One side					S1109BRX	0.4	◆Door trim assembly, R&R
INNER HANDLE COVER, R&R	One or both sides						S1110ARX	0.2	
DOOR WEATHERSTRIP, R&R	Both sides						S1120ARX	0.5	◆Water leak, Check
DOOR WEATHERSTRIP, R&R	One side						S1120BRX	0.3	◆Water leak, Check
INNER WEATHERSTRIP, R&R	Rear door glass weatherstrip	Both sides					S1122ARX	0.6	◆Door trim assembly, R&R
INNER WEATHERSTRIP, R&R	Rear door glass weatherstrip	One side					S1122BRX	0.4	◆Door trim assembly, R&R
DOOR TRIM, R&R	Lower	Both sides					S1125ARX	0.3	
DOOR TRIM, R&R	Lower	One side					S1125BRX	0.2	
DOOR TRIM, R&R	Upper	Both sides					S1125CRX	0.5	
DOOR TRIM, R&R	Upper	One side					S1125DRX	0.3	
DOOR STRIKER, R&R	Lower	Both sides					S1129ARX	0.3	◆Striker, Adjust
DOOR STRIKER, R&R	Lower	One side					S1129BRX	0.2	◆Striker, Adjust
DOOR STRIKER, R&R	Upper	Both sides					S1129CRX	0.3	◆Striker, Adjust
DOOR STRIKER, R&R	Upper	One side					S1129DRX	0.2	◆Striker, Adjust
S12 LIFTGATE									
LIFTGATE BODY, R&R	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming					S1201ARX	3.7	◆Rear window glass (S1402), R&R◆Liftgate, Adjust◆Water leak, Check
LIFTGATE BODY, R&R	With 360°view monitor system	360°view monitor system screen display verification only					S1201BRX	3.7	◆Rear window glass (S1402), R&R◆Liftgate, Adjust◆Water leak, Check
LIFTGATE BODY, R&R	Without 360°view monitor system	With advanced keyless entry system					S1201CRX	3.6	◆Rear window glass (S1402), R&R◆Liftgate, Adjust◆Water leak, Check
LIFTGATE BODY, R&R	Without 360°view monitor system	Without advanced keyless entry system					S1201DRX	3.5	◆Rear window glass (S1402), R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1203ARX	2.4	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification only				S1203BRX	2.3	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	Both sides	Without 360°view monitor system					S1203CRX	2.2	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
HINGE, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1203DRX	2.3	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification only				S1203ERX	2.3	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	One side	Without 360°view monitor system	With advanced keyless entry system				S1203FRX	2.2	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
HINGE, R&R	One side	Without 360°view monitor system	Without advanced keyless entry system				S1203GRX	2.1	◆Liftgate assembly, R&R◆Liftgate, Adjust◆Water leak, Check
LOCK, R&R							S1204ARX	0.4	◆Liftgate trim (S1218), R&R
STRIKER, R&R							S1207ARX	0.2	◆Striker, Adjust
DAMPER STAY, R&R	Both sides						S1212ARX	0.3	
DAMPER STAY, R&R	One side						S1212BRX	0.2	
WEATHERSTRIP, R&R							S1217ARX	0.3	◆Water leak, Check
LIFTGATE TRIM, R&R	Lower	With advanced keyless entry system					S1218ARX	0.3	
LIFTGATE TRIM, R&R	Lower	Without advanced keyless entry system					S1218BRX	0.2	
LIFTGATE TRIM, R&R	Side	One or both sides					S1218CRX	0.2	
LIFTGATE TRIM, R&R	Upper						S1218DRX	0.2	
<b>S14 WINDOW GLASSES</b>									
WINDSHIELD GLASS, R&R							S1401ARX	3.2	◆Front window molding (S0401), R&R◆Water leak, Check◆Forward sensing camera [FSC], Aiming
REAR WINDOW GLASS, R&R							S1402ARX	2.5	◆Water leak, Check
QUARTER WINDOW GLASS & DAM, R&R	Both sides						S1412ARX	1.8	◆Water leak, Check
QUARTER WINDOW GLASS & DAM, R&R	Left side						S1412BRX	1.1	◆Water leak, Check
QUARTER WINDOW GLASS & DAM, R&R	Right side						S1412CRX	1.0	◆Water leak, Check
<b>S15 SUNROOF</b>									
ROOF PANEL, R&R							S1503ARX	0.4	
SUNROOF FRAME, R&R							S1509ARX	1.7	◆Sunroof assembly, R&R
GUIDES [ALL], R&R							S1510ARX	1.7	◆Sunroof assembly, R&R
DEFLECTOR, R&R							S1512ARX	0.2	
SUNROOF MOTOR, R&R							S1514ARX	0.3	
DRAIN HOSE, R&R	Front	Driver side					S1519ARX	3.3	◆Headliner (S1701), R&R
DRAIN HOSE, R&R	Front	Passenger side					S1519BRX	3.4	◆Headliner (S1701), R&R
DRAIN HOSE, R&R	Rear	Left side					S1519CRX	2.6	◆Headliner (S1701), R&R
DRAIN HOSE, R&R	Rear	Right side					S1519DRX	2.6	◆Headliner (S1701), R&R
SUNROOF WEATHERSTRIP, R&R							S1520ARX	0.5	◆Roof panel (S1503), R&R
SUNSHADE, R&R							S1521ARX	1.4	◆Sunroof assembly, R&R

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SUNROOF SWITCH AND/OR TILT SWITCH, R&R							S1522ARX	0.2	
<b>S16 WIPERS &amp; WASHERS</b>									
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer motor	Front and rear washer motor					S1601ARX	0.4	
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system			S1601BRX	1.0	◆Front bumper assembly, R&R
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system			S1601CRX	1.0	◆Front bumper assembly, R&R
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system			S1601DRX	0.9	◆Front bumper assembly, R&R
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system			S1601ERX	0.9	◆Front bumper assembly, R&R
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	Without 360°view monitor system	With front cross traffic alert (FCTA) system				S1601FRX	0.9	◆Front bumper assembly, R&R
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	Without 360°view monitor system	Without front cross traffic alert (FCTA) system				S1601GRX	0.8	◆Front bumper assembly, R&R
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose A						S1602ARX	0.4	
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose B						S1602BRX	2.8	
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose C						S1602CRX	2.6	◆Instrument panel assembly, R&R
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose D	With sunroof					S1602DRX	1.0	◆Headliner (S1701), D&C
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose D	Without sunroof					S1602ERX	0.9	◆Headliner (S1701), D&C
WASHER PIPES AND/OR HOSES [ALL], R&R	Rear washer hose E						S1602FRX	1.0	◆Headliner (S1701), D&C
WASHER PIPES AND/OR HOSES [ALL], R&R	Windshield washer hose A						S1602GRX	0.6	
WASHER PIPES AND/OR HOSES [ALL], R&R	Windshield washer hose B						S1602HRX	0.2	
WASHER PIPES AND/OR HOSES [ALL], R&R	Windshield washer hose C						S1602JRX	0.2	
FRONT WASHER NOZZLE [ONE OR ALL], R&R							S1603ARX	0.2	
TANK CAP, R&R							S1604ARX	0.2	

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT WIPER BLADE AND ARM [ONE OR ALL], R&R							S1605ARX	0.3	
FRONT WIPER LINK AND/OR FRAME, R&R							S1606ARX	0.5	◆Cowl grille (S0412), R&R◆Front wiper motor (S1607), R&R
FRONT WIPER MOTOR, R&R							S1607ARX	0.5	◆Cowl grille assembly, R&R
SEAL CAP [ALL], R&R	Outer bushing						S1608ARX	0.4	
FRONT & REAR WIPER ARM COVER [ALL], R&R							S1609ARX	0.2	
REAR WASHER NOZZLE, R&R							S1611ARX	0.4	◆Rear spoiler assembly, R&R
REAR WIPER BLADE AND/OR ARM, R&R							S1612ARX	0.2	
REAR WIPER MOTOR, R&R							S1613ARX	0.4	◆Liftgate trim (S1218), R&R
WIPER SWITCH, R&R							S1614ARX	1.0	◆Steering column cover (S0706), R&R
RAIN SENSOR, R&R							S1618ARX	0.3	
<b>S17 TRIMS &amp; MATS</b>									
HEADLINER, R&R							S1701ARX	0.9	
"A" PILLAR TRIM, R&R	Front pillar trim	Both sides					S1702ARX	0.2	
"A" PILLAR TRIM, R&R	Front pillar trim	One side					S1702BRX	0.2	
"B" PILLAR TRIM, R&R	Rear pillar trim	Both sides	With Bose				S1703ARX	0.4	
"B" PILLAR TRIM, R&R	Rear pillar trim	Both sides	Without Bose				S1703BRX	0.3	
"B" PILLAR TRIM, R&R	Rear pillar trim	One side	With Bose				S1703CRX	0.3	
"B" PILLAR TRIM, R&R	Rear pillar trim	One side	Without Bose				S1703DRX	0.2	
FRONT SIDE TRIM, R&R	One or both sides						S1705ARX	0.2	
TRUNK SIDE TRIM, R&R	Both sides						S1707ARX	0.8	
TRUNK SIDE TRIM, R&R	Left side						S1707BRX	0.6	
TRUNK SIDE TRIM, R&R	Right side						S1707CRX	0.5	
TRUNK END TRIM, R&R							S1709ARX	0.2	
LUGGAGE COMPARTMENT COVER, R&R							S1712ARX	0.2	
FRONT SCUFF PLATE, R&R	One or both sides						S1713ARX	0.2	
FRONT FLOOR MAT, R&R							S1715ARX	1.4	
TRUNK ROOM MAT, R&R	Trunk board						S1718ARX	0.2	
REAR FLOOR MAT, R&R							S1726ARX	1.0	
<b>S18 MIRRORS &amp; VISORS</b>									
OUTSIDE MIRROR, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1801ARX	1.4	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	Both sides	With 360°view monitor system	360°view monitor system screen display verification only				S1801BRX	1.1	◆Door trim assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OUTSIDE MIRROR, R&R	Both sides	Without 360°view monitor system					S1801CRX	0.9	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming				S1801DRX	0.9	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	One side	With 360°view monitor system	360°view monitor system screen display verification only				S1801ERX	0.7	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	One side	Without 360°view monitor system					S1801FRX	0.6	◆Door trim assembly, R&R
OUTSIDE MIRROR GLASS, R&R	Both sides						S1802ARX	0.3	
OUTSIDE MIRROR GLASS, R&R	One side						S1802BRX	0.2	
REARVIEW MIRROR, R&R							S1803ARX	0.3	
SAIL GARNISH, R&R	One or both sides						S1805ARX	0.2	
SUN VISOR, R&R	Both sides	With vanity mirror illumination					S1806ARX	0.3	
SUN VISOR, R&R	Both sides	Without vanity mirror illumination					S1806BRX	0.2	
SUN VISOR, R&R	One side	With vanity mirror illumination					S1806CRX	0.3	
SUN VISOR, R&R	One side	Without vanity mirror illumination					S1806DRX	0.2	
<b>S19 SPOILERS</b>									
REAR SPOILER, R&R							S1903ARX	0.5	
<b>S22 AIR BAG SYSTEM</b>									
AIR BAG MODULE, R&R	Curtain air bag module	Both sides					S2201ARX	1.1	◆Headliner (S1701), R&R
AIR BAG MODULE, R&R	Curtain air bag module	One side					S2201BRX	1.0	◆Headliner (S1701), R&R
AIR BAG MODULE, R&R	Far side air bag module	With walk in switch					S2201CRX	0.8	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Far side air bag module	Without walk in switch					S2201DRX	0.7	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Front air bag module	Driver side					S2201ERX	0.3	
AIR BAG MODULE, R&R	Front air bag module	Passenger side					S2201FRX	0.3	
AIR BAG MODULE, R&R	Knee air bag module						S2201GRX	0.5	
AIR BAG MODULE, R&R	Side air bag module for front passenger	Both sides	With walk in switch				S2201HRX	1.3	◆Front seat assembly (S0901), R&R



## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
AIR BAG MODULE, R&R	Side air bag module for front passenger	Both sides	Without walk in switch				S2201JRX	1.2	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag module for front passenger	Driver side	With walk in switch				S2201KRX	0.8	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag module for front passenger	Driver side	Without walk in switch				S2201LRX	0.7	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag module for front passenger	Passenger side					S2201MRX	0.7	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag module for rear passenger	Both sides					S2201NRX	0.6	
AIR BAG MODULE, R&R	Side air bag module for rear passenger	Left side					S2201PRX	0.5	
AIR BAG MODULE, R&R	Side air bag module for rear passenger	Right side					S2201QRX	0.4	
AIR BAG SENSOR, R&R	Crash zone sensor	Both sides	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming			S2202ARX	1.2	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	Both sides	With 360°view monitor system	360°view monitor system screen display verification only	With front cross traffic alert (FCTA) system		S2202BRX	1.2	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	Both sides	With 360°view monitor system	360°view monitor system screen display verification only	Without front cross traffic alert (FCTA) system		S2202CRX	1.1	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	Both sides	Without 360°view monitor system				S2202DRX	1.1	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	With front cross traffic alert (FCTA) system		S2202ERX	1.1	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	One side	With 360°view monitor system	360°view monitor system screen display verification and 360°view monitor system aiming	Without front cross traffic alert (FCTA) system		S2202FRX	1.0	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	One side	With 360°view monitor system	360°view monitor system screen display verification only			S2202GRX	1.0	◆Front bumper assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
AIR BAG SENSOR, R&R	Crash zone sensor	One side	Without 360°view monitor system	With front cross traffic alert (FCTA) system			S2202HRX	1.0	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Crash zone sensor	One side	Without 360°view monitor system	Without front cross traffic alert (FCTA) system			S2202JRX	0.9	◆Front bumper assembly, R&R
AIR BAG SENSOR, R&R	Pressure sensor	Both sides					S2202KRX	0.6	◆Door trim assembly, R&R
AIR BAG SENSOR, R&R	Pressure sensor	One side					S2202LRX	0.4	◆Door trim assembly, R&R
AIR BAG SENSOR, R&R	Seat track position sensor						S2202MRX	0.3	
AIR BAG SENSOR, R&R	Side air bag sensor No.1	Both sides					S2202NRX	0.6	◆Door trim assembly, R&R
AIR BAG SENSOR, R&R	Side air bag sensor No.1	One side					S2202PRX	0.4	◆Door trim assembly, R&R
AIR BAG SENSOR, R&R	Side air bag sensor No.2	Both sides					S2202QRX	0.6	
AIR BAG SENSOR, R&R	Side air bag sensor No.2	Left side					S2202RRX	0.5	
AIR BAG SENSOR, R&R	Side air bag sensor No.2	Right side					S2202SRX	0.4	
AIR BAG CONTROL UNIT, R&R	SAS unit						S2206ARX	0.6	◆Rear console (S0803), R&R