

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
M01 DRIVE SHAFT									
FRONT DRIVE SHAFT, R&R	2WD	Both sides					M0101ARX	1.4	
FRONT DRIVE SHAFT, R&R	2WD	Left side					M0101BRX	1.0	
FRONT DRIVE SHAFT, R&R	2WD	Right side					M0101CRX	0.9	
FRONT DRIVE SHAFT, R&R	4WD	Both sides					M0101DRX	1.6	
FRONT DRIVE SHAFT, R&R	4WD	Left side					M0101ERX	1.0	
FRONT DRIVE SHAFT, R&R	4WD	Right side					M0101FRX	1.1	
REAR DRIVE SHAFT, R&R	Both sides						M0102ARX	1.2	
REAR DRIVE SHAFT, R&R	One side						M0102BRX	0.8	
OUTER JOINT SET [FRONT], R&R	2WD	Both sides					M0103ARX	2.1	◆Front drive shaft (M0101), R&R
OUTER JOINT SET [FRONT], R&R	2WD	One side					M0103BRX	1.3	◆Front drive shaft (M0101), R&R
OUTER JOINT SET [FRONT], R&R	4WD	Both sides					M0103CRX	2.3	◆Front drive shaft (M0101), R&R
OUTER JOINT SET [FRONT], R&R	4WD	Left side					M0103DRX	1.4	◆Front drive shaft (M0101), R&R
OUTER JOINT SET [FRONT], R&R	4WD	Right side					M0103ERX	1.5	◆Front drive shaft (M0101), R&R
OUTER JOINT SET [REAR], R&R	Both sides						M0104ARX	2.4	◆Rear drive shaft (M0102), R&R
OUTER JOINT SET [REAR], R&R	One side						M0104BRX	1.5	◆Rear drive shaft (M0102), R&R
INNER JOINT SET [FRONT], R&R	2WD	Both sides					M0105ARX	2.0	◆Front drive shaft (M0101), R&R
INNER JOINT SET [FRONT], R&R	2WD	Left side					M0105BRX	1.3	◆Front drive shaft (M0101), R&R
INNER JOINT SET [FRONT], R&R	2WD	Right side					M0105CRX	1.2	◆Front drive shaft (M0101), R&R
INNER JOINT SET [FRONT], R&R	4WD	Both sides					M0105DRX	2.2	◆Front drive shaft (M0101), R&R
INNER JOINT SET [FRONT], R&R	4WD	Left side					M0105ERX	1.3	◆Front drive shaft (M0101), R&R
INNER JOINT SET [FRONT], R&R	4WD	Right side					M0105FRX	1.4	◆Front drive shaft (M0101), R&R
INNER JOINT SET [REAR], R&R	Both sides						M0106ARX	1.8	◆Rear drive shaft (M0102), R&R
INNER JOINT SET [REAR], R&R	One side						M0106BRX	1.1	◆Rear drive shaft (M0102), R&R
BALL BEARING, DUST SEAL AND/OR BRACKET, R&R	2WD						M0107ARX	1.1	◆Front drive shaft (M0101), R&R [Right side]
BALL BEARING, DUST SEAL AND/OR BRACKET, R&R	4WD						M0107BRX	1.3	◆Front drive shaft (M0101), R&R [Right side]
DRIVE BOOT SET [FRONT], R&R	2WD	Both sides					M0108ARX	2.1	◆Front drive shaft (M0101), R&R
DRIVE BOOT SET [FRONT], R&R	2WD	One side					M0108BRX	1.3	◆Front drive shaft (M0101), R&R
DRIVE BOOT SET [FRONT], R&R	4WD	Both sides					M0108CRX	2.3	◆Front drive shaft (M0101), R&R
DRIVE BOOT SET [FRONT], R&R	4WD	Left side					M0108DRX	1.4	◆Front drive shaft (M0101), R&R
DRIVE BOOT SET [FRONT], R&R	4WD	Right side					M0108ERX	1.5	◆Front drive shaft (M0101), R&R

ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
DRIVE BOOT SET [REAR], R&R	Both sides						M0109ARX	2.4	◆Rear drive shaft (M0102), R&R
DRIVE BOOT SET [REAR], R&R	One side						M0109BRX	1.5	◆Rear drive shaft (M0102), R&R
CLIP, R&R	Front						M0111ARX	1.0	◆Front drive shaft (M0101), D&C
CLIP, R&R	Rear	Both sides					M0111BRX	1.2	◆Rear drive shaft (M0102), R&R
CLIP, R&R	Rear	One side					M0111CRX	0.8	◆Rear drive shaft (M0102), R&R
M02 FRONT AXLE									
STEERING KNUCKLE, R&R	Both sides						M0201ARX	1.2	◆Front wheel hub assembly, R&R
STEERING KNUCKLE, R&R	One side						M0201BRX	0.7	◆Front wheel hub assembly, R&R
FRONT WHEEL HUB, R&R	Both sides						M0203ARX	0.7	◆Disc plate (P0102), R&R
FRONT WHEEL HUB, R&R	One side						M0203BRX	0.5	◆Disc plate (P0102), R&R
FRONT WHEEL HUB BOLTS, R&R	Both sides						M0204ARX	0.9	◆Disc plate (P0102), R&R
FRONT WHEEL HUB BOLTS, R&R	One side						M0204BRX	0.6	◆Disc plate (P0102), R&R
LOCK NUT OR LOCK BOLT, R&R	Both sides						M0206ARX	0.3	
LOCK NUT OR LOCK BOLT, R&R	One side						M0206BRX	0.3	
M03 REAR AXLE									
REAR AXLE LOCK NUT, R&R	Both sides						M0302ARX	0.3	
REAR AXLE LOCK NUT, R&R	One side						M0302BRX	0.3	
REAR WHEEL HUB BOLTS, R&R	Both sides						M0303ARX	1.2	◆Disc plate (P0208), R&R
REAR WHEEL HUB BOLTS, R&R	One side						M0303BRX	0.7	◆Disc plate (P0208), R&R
REAR WHEEL HUB, R&R	2WD	Both sides					M0314ARX	0.8	◆Disc plate (P0208), R&R
REAR WHEEL HUB, R&R	2WD	One side					M0314BRX	0.6	◆Disc plate (P0208), R&R
REAR WHEEL HUB, R&R	4WD	Both sides					M0314CRX	1.0	◆Disc plate (P0208), R&R
REAR WHEEL HUB, R&R	4WD	One side					M0314DRX	0.6	◆Disc plate (P0208), R&R
M04 DIFFERENTIAL (Except FWD)									
DIFFERENTIAL ASSEMBLY, OH							M0401AHX	5.2	◆Differential assembly (M0401), R&R
DIFFERENTIAL ASSEMBLY, R&R							M0401ARX	2.9	◆Propeller shaft assembly (L0101), R&R
OIL SEAL, R&R							M0403ARX	2.1	◆Propeller shaft assembly (L0101), R&R
FINAL GEAR SET, R&R							M0404ARX	4.9	◆Differential assembly (M0401), R&R
BEARING [DRIVE PINION] [ALL], R&R							M0405ARX	4.8	◆Differential assembly (M0401), R&R
DIFFERENTIAL CARRIER, R&R							M0406ARX	4.8	◆Differential assembly (M0401), R&R
OIL SEAL [OUTPUT SHAFT AND SIDE HOUSING], R&R	Both sides						M0407ARX	1.2	◆Rear drive shaft (M0102), R&R
OIL SEAL [OUTPUT SHAFT AND SIDE HOUSING], R&R	One side						M0407BRX	0.8	◆Rear drive shaft (M0102), R&R
DIFFERENTIAL PINION GEAR, SIDE GEAR AND/OR PINION SHAFT, R&R							M0408ARX	4.9	◆Propeller shaft assembly (L0101), R&R◆Differential assembly (M0401), R&R
BEARING [GEAR CASE] [ALL], R&R							M0409ARX	4.9	◆Differential assembly (M0401), R&R

ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
DIFFERENTIAL MOUNT RUBBER, R&R	All						M0412ARX	0.5	
DIFFERENTIAL MOUNT RUBBER, R&R	Front side	Both sides					M0412BRX	0.5	
DIFFERENTIAL MOUNT RUBBER, R&R	Front side	One side					M0412CRX	0.3	
DIFFERENTIAL MOUNT RUBBER, R&R	Rear side						M0412DRX	0.3	