

## ILLUSTRATION

OPERATION	VARIATION 1	VARIATION 2	VARIATION 3	VARIATION 4	VARIATION 5	OTHER VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
G01 ENGINE ELECTRICAL									
IGNITION COIL [ALL], R&R							G0101ARX	0.3	
SPARK PLUG [ALL], R&R							G0102ARX	0.4	◆ Ignition coil (G0101), R&R
G03 GENERATOR									
GENERATOR DRIVE BELT, R&R							G0303ARX	0.6	
GENERATOR DRIVE BELT TENSIONER, R&R							G0308ARX	0.6	◆ Generator drive belt (G0303), R&R
INTEGRATED STARTER GENERATOR, R&R							G0309ARX	1.7	◆ Cooling fan assembly (E0204), R&R
G04 STARTER									
STARTER, R&R							G0401ARX	0.6	
G05 BATTERY									
BATTERY INSPECTION, CHARGE AND TEST							G0501ACX	0.5	◆ Battery (G0501), R&R◆ Battery load test◆ Charging and capacity test◆ Charging system test◆ Dark current test
BATTERY, R&R							G0501ARX	0.3	
BATTERY BOX COVER, R&R							G0502ARX	0.3	
BATTERY CARRIER, R&R							G0503ARX	0.5	
BATTERY CLAMP AND/OR CLAMP BOLT [ALL], R&R							G0504ARX	0.2	
DC-DC CONVERTER, R&R							G0506ARX	1.1	
LITHIUM ION BATTERY, R&R							G0513ARX	1.0	