

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
D01 OIL PUMP & FILTER				
OIL PUMP ASSEMBLY AND/OR GASKET, R&R	Without i-stop	D0101ARX	1.4	◆Oil pan gasket (D0201), R&R
OIL PUMP ASSEMBLY AND/OR GASKET, R&R	With i-stop	D0101BRX	1.5	◆Oil pan gasket (D0201), R&R
OIL FILTER CARTRIDGE, R&R		D0102XRX	0.4	
OIL COOLER AND/OR "O" RING, R&R	SKYACTIV-G 2.0, Without i-stop	D0103ARX	1.1	
OIL COOLER AND/OR "O" RING, R&R	SKYACTIV-G 2.0, With i-stop	D0103BRX	1.2	
OIL STRAINER AND/OR GASKET, R&R		D0104XRX	1.1	◆Oil pan gasket (D0201), R&R
ENGINE OIL SOLENOID VALVE, R&R	Without i-stop	D0110ARX	0.5	
ENGINE OIL SOLENOID VALVE, R&R	With i-stop	D0110BRX	0.6	
D02 OIL PAN				
OIL PAN AND/OR GASKET, R&R		D0201XRX	1.0	
OIL PAN DRAIN PLUG AND/OR GASKET, R&R		D0202XRX	0.4	
OIL PAN BOLT [ALL], R&R		D0203XRX	1.0	
OIL FILLER CAP AND/OR GASKET, R&R		D0204XRX	0.2	
OIL LEVEL GAUGE, R&R		D0205XRX	0.2	
OIL JET AND/OR GASKET [ALL], R&R	[6MT, Without i-stop, PCM cover with standard bolts, Without front suspension tower bar]/[6MT, Without i-stop, PCM cover with standard bolts, With front suspension tower bar, Without engine oil cooler]	D0207ARX	13.5	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OIL JET AND/OR GASKET [ALL], R&R	[6MT,Without i-stop,PCM cover with standard bolts,With front suspension tower bar,With engine oil cooler]/[6MT,Without i-stop,PCM cover with shear-off bolts,Without front suspension tower bar]/[6MT,Without i-stop,PCM cover with shear-off bolts,With front suspension tower bar,Without engine oil cooler]/[6MT,With i-stop,PCM cover with standard bolts,Without front suspension tower bar]	D0207BRX	13.6	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	[6MT,Without i-stop,PCM cover with shear-off bolts,With front suspension tower bar,With engine oil cooler]/[6MT,With i-stop,PCM cover with standard bolts,With front suspension tower bar]/[6MT,With i-stop,PCM cover with shear-off bolts,Without front suspension tower bar]	D0207CRX	13.7	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	6MT,With i-stop,PCM cover with shear-off bolts,With front suspension tower bar	D0207DRX	13.8	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	6AT,Without i-stop,PCM cover with standard bolts,Without front suspension tower bar	D0207ERX	13.5	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	[6AT,Without i-stop,PCM cover with standard bolts,With front suspension tower bar]/[6AT,Without i-stop,PCM cover with shear-off bolts,Without front suspension tower bar]	D0207FRX	13.6	◆Front crossmember assembly, R&R◆ Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
OIL JET AND/OR GASKET [ALL], R&R	[6AT,Without i-stop,PCM cover with shear-off bolts,With front suspension tower bar]/[6AT,With i-stop,Without front suspension tower bar]	D0207GRX	13.7	◆Front crossmember assembly, R&R◆Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R
OIL JET AND/OR GASKET [ALL], R&R	6AT,With i-stop,With front suspension tower bar	D0207HRX	13.8	◆Front crossmember assembly, R&R◆Engine (B0101), R&R◆Oil pan gasket (D0201), R&R◆Crankshaft (B0502), R&R