

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
H01 FLYWHEEL				
FLYWHEEL ASSEMBLY, R&R	LHD,Without i-stop,Without front suspension tower bar	H0101ARX	5.0	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	LHD,Without i-stop,With front suspension tower bar	H0101BRX	5.1	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	LHD,With i-stop,Without front suspension tower bar,Without center under cover	H0101CRX	5.3	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	[LHD,With i-stop,Without front suspension tower bar,With center under cover]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0101DRX	5.4	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0101ERX	5.5	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	RHD,Without i-stop,Without front suspension tower bar	H0101FRX	5.1	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	RHD,Without i-stop,With front suspension tower bar	H0101GRX	5.2	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
FLYWHEEL ASSEMBLY, R&R	RHD,With i-stop	H0101HRX	5.3	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	LHD,Without i-stop,Without front suspension tower bar	H0103ARX	4.8	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	LHD,Without i-stop,With front suspension tower bar	H0103BRX	4.9	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
PILOT BEARING, R&R	[LHD,With i-stop,Without front suspension tower bar]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0103CRX	5.2	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0103DRX	5.3	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	RHD,Without i-stop,Without front suspension tower bar	H0103ERX	4.9	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	RHD,Without i-stop,With front suspension tower bar	H0103FRX	5.0	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
PILOT BEARING, R&R	RHD,With i-stop	H0103GRX	5.1	Transmission assembly, R&R Clutch cover (H0201), R&R Clutch disc (H0202), R&R
H02 CLUTCH DISC				
CLUTCH COVER, R&R	LHD,Without i-stop	H0201ARX	4.8	Transmission assembly, R&R
CLUTCH COVER, R&R	LHD,With i-stop,Without front suspension tower bar,Without center under cover	H0201BRX	5.1	Transmission assembly, R&R
CLUTCH COVER, R&R	[LHD,With i-stop,Without front suspension tower bar,With center under cover]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0201CRX	5.2	Transmission assembly, R&R
CLUTCH COVER, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0201DRX	5.3	Transmission assembly, R&R
CLUTCH COVER, R&R	RHD,Without i-stop,Without front suspension tower bar	H0201ERX	4.9	Transmission assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
CLUTCH COVER, R&R	[RHD,Without i-stop,With front suspension tower bar]/[RHD,With i-stop,Without front suspension tower bar]	H0201FRX	5.0	Transmission assembly, R&R
CLUTCH COVER, R&R	RHD,With i-stop,With front suspension tower bar	H0201GRX	5.1	Transmission assembly, R&R
CLUTCH DISC, R&R	LHD,Without i-stop	H0202ARX	4.8	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	LHD,With i-stop,Without front suspension tower bar,Without center under cover	H0202BRX	5.1	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	[LHD,With i-stop,Without front suspension tower bar,With center under cover]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0202CRX	5.2	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0202DRX	5.3	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	RHD,Without i-stop,Without front suspension tower bar	H0202ERX	4.9	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	[RHD,Without i-stop,With front suspension tower bar]/[RHD,With i-stop,Without front suspension tower bar]	H0202FRX	5.0	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH DISC, R&R	RHD,With i-stop,With front suspension tower bar	H0202GRX	5.1	Transmission assembly, R&R Clutch cover (H0201), R&R
CLUTCH RELEASE COLLAR, R&R	LHD,Without i-stop	H0203ARX	4.6	Transmission assembly, R&R
CLUTCH RELEASE COLLAR, R&R	LHD,With i-stop,Without front suspension tower bar,Without center under cover	H0203BRX	4.9	Transmission assembly, R&R
CLUTCH RELEASE COLLAR, R&R	[LHD,With i-stop,Without front suspension tower bar,With center under cover]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0203CRX	5.0	Transmission assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
CLUTCH RELEASE COLLAR, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0203DRX	5.1	Transmission assembly, R&R
CLUTCH RELEASE COLLAR, R&R	RHD,Without i-stop,Without front suspension tower bar	H0203ERX	4.7	Transmission assembly, R&R
CLUTCH RELEASE COLLAR, R&R	[RHD,Without i-stop,With front suspension tower bar]/[RHD,With i-stop,Without front suspension tower bar]	H0203FRX	4.8	Transmission assembly, R&R
CLUTCH RELEASE COLLAR, R&R	RHD,With i-stop,With front suspension tower bar	H0203GRX	4.9	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	LHD,Without i-stop	H0204ARX	4.6	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	LHD,With i-stop,Without front suspension tower bar,Without center under cover	H0204BRX	4.9	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	[LHD,With i-stop,Without front suspension tower bar,With center under cover]/[LHD,With i-stop,With front suspension tower bar,Without center under cover]	H0204CRX	5.0	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	LHD,With i-stop,With front suspension tower bar,With center under cover	H0204DRX	5.1	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	RHD,Without i-stop,Without front suspension tower bar	H0204ERX	4.7	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	[RHD,Without i-stop,With front suspension tower bar]/[RHD,With i-stop,Without front suspension tower bar]	H0204FRX	4.8	Transmission assembly, R&R
CLUTCH RELEASE FORK, R&R	RHD,With i-stop,With front suspension tower bar	H0204GRX	4.9	Transmission assembly, R&R
H03 CLUTCH MASTER & RELEASE CYLINDER				
CLUTCH MASTER CYLINDER, R&R	Without i-stop	H0301ARX	0.9	Clutch line (A0122), Air bleed
CLUTCH MASTER CYLINDER, R&R	With i-stop	H0301BRX	1.0	Clutch line (A0122), Air bleed
CLUTCH RELEASE CYLINDER, R&R		H0302XRX	0.4	Clutch line (A0122), Air bleed
CLUTCH PIPE, R&R	No.1,LHD,Without plate	H0304ARX	0.3	Clutch line (A0122), Air bleed
CLUTCH PIPE, R&R	No.1,LHD,With plate	H0304BRX	0.4	Clutch line (A0122), Air bleed
CLUTCH PIPE, R&R	No.1,RHD	H0304CRX	0.5	Clutch line (A0122), Air bleed

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
CLUTCH PIPE, R&R	No.2,Without plate	H0304DRX	0.5	Clutch line (A0122), Air bleed
CLUTCH PIPE, R&R	No.2,With plate	H0304ERX	0.6	Clutch line (A0122), Air bleed
FLEXIBLE HOSE, R&R		H0305XRX	0.4	Clutch line (A0122), Air bleed
H04 CLUTCH PEDAL				
CLUTCH PEDAL AND/OR BUSH, R&R	LHD,Without i-stop,Without plate	H0401ARX	0.9	Clutch line (A0122), Air bleed
CLUTCH PEDAL AND/OR BUSH, R&R	[LHD,Without i-stop,With plate]/[LHD,With i-stop]	H0401BRX	1.0	Clutch line (A0122), Air bleed
CLUTCH PEDAL AND/OR BUSH, R&R	RHD,Without i-stop	H0401CRX	0.9	Clutch line (A0122), Air bleed
CLUTCH PEDAL AND/OR BUSH, R&R	RHD,With i-stop	H0401DRX	1.0	Clutch line (A0122), Air bleed
CLUTCH SWITCH, R&R	Without i-stop	H0405ARX	0.2	
CLUTCH SWITCH, R&R	With i-stop	H0405BRX	0.3	
PEDAL PAD, R&R		H0406XRX	0.2	