

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
S01 LOCK SET				
DOOR LOCK SUB SET, R&R		S0102XRX	0.2	
S02 BUMPER				
FRONT BUMPER, R&R	<i>Front bumper face,Without headlight washer,Without i-stop</i>	S0201ARX	1.0	
FRONT BUMPER, R&R	<i>Front bumper face,Without headlight washer,With i-stop</i>	S0201BRX	1.0	
FRONT BUMPER, R&R	<i>Front bumper face,With headlight washer,Without i-stop</i>	S0201CRX	1.0	
FRONT BUMPER, R&R	<i>Front bumper face,With headlight washer,With i-stop</i>	S0201DRX	1.1	
FRONT BUMPER, R&R	<i>Front bumper reinforcement,Without i-stop</i>	S0201ERX	1.4	
FRONT BUMPER, R&R	<i>Front bumper reinforcement,With i-stop</i>	S0201FRX	1.5	
RADIATOR GRILLE, R&R	Without i-stop	S0204ARX	0.8	◆Front bumper assembly, R&R
RADIATOR GRILLE, R&R	With i-stop	S0204BRX	0.9	◆Front bumper assembly, R&R
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,Without blind spot monitoring (BSM),Without rear mount camera,Without i-stop</i>	S0206ARX	0.8	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,Without blind spot monitoring (BSM),Without rear mount camera,With i-stop</i>	S0206BRX	0.9	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,Without blind spot monitoring (BSM),With rear mount camera,Without i-stop</i>	S0206LRX	0.9	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,Without blind spot monitoring (BSM),With rear mount camera,With i-stop</i>	S0206MRX	1.0	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,With blind spot monitoring (BSM),Without rear mount camera,Without i-stop</i>	S0206CRX	1.0	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,With blind spot monitoring (BSM),Without rear mount camera,With i-stop</i>	S0206DRX	1.1	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,With blind spot monitoring (BSM),With rear mount camera,Without i-stop</i>	S0206NRX	1.1	
REAR BUMPER, R&R	<i>Rear bumper face,Without ultrasonic sensor,With blind spot monitoring (BSM),With rear mount camera,With i-stop</i>	S0206PRX	1.2	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,Without blind spot monitoring (BSM),Without rear mount camera,Without i-stop</i>	S0206ERX	0.9	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,Without blind spot monitoring (BSM),Without rear mount camera,With i-stop</i>	S0206FRX	1.0	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,Without blind spot monitoring (BSM),With rear mount camera</i>	S0206QRX	1.0	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,With blind spot monitoring (BSM),Without rear mount camera,Without i-stop</i>	S0206GRX	1.1	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,With blind spot monitoring (BSM),Without rear mount camera,With i-stop</i>	S0206HRX	1.2	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,With blind spot monitoring (BSM),With rear mount camera,Without i-stop</i>	S0206RRX	1.2	
REAR BUMPER, R&R	<i>Rear bumper face,With ultrasonic sensor,With blind spot monitoring (BSM),With rear mount camera,With i-stop</i>	S0206SRX	1.3	
REAR BUMPER, R&R	<i>Rear bumper reinforcement,Without i-stop</i>	S0206JRX	0.9	
REAR BUMPER, R&R	<i>Rear bumper reinforcement,With i-stop</i>	S0206KRX	1.0	
S03 HEAD LIGHT CLEANER				
WASHER NOZZLE, R&R	One or both sides,Without i-stop	S0301ARX	0.5	
WASHER NOZZLE, R&R	One or both sides,With i-stop	S0301BRX	0.6	
S04 MOLDINGS & PROTECTORS				
FRONT WINDOW MOLDINGS, R&R	Front windshield garnish,Without i-stop	S0401ARX	0.4	
FRONT WINDOW MOLDINGS, R&R	Front windshield garnish,With i-stop	S0401BRX	0.5	
FRONT WINDOW MOLDINGS, R&R	A pillar garnish,One or both sides,Without i-stop	S0401CRX	0.4	
FRONT WINDOW MOLDINGS, R&R	A pillar garnish,One or both sides,With i-stop	S0401DRX	0.5	
FRONT BELT LINE MOLDING, R&R	One or both sides	S0405XRX	0.2	
COWL GRILLE, R&R		S0412XRX	0.4	
EXTRACTOR CHAMBER, R&R	One side,Without i-stop	S0416ARX	0.7	◆Rear bumper assembly, R&R
EXTRACTOR CHAMBER, R&R	One side,With i-stop	S0416BRX	0.8	◆Rear bumper assembly, R&R
EXTRACTOR CHAMBER, R&R	Both sides	S0416CRX	0.8	◆Rear bumper assembly, R&R
ORNAMENT [REAR], R&R		S0417XRX	0.2	
ORNAMENT [FRONT], R&R	Without i-stop	S0420ARX	0.8	◆Front bumper assembly, R&R
ORNAMENT [FRONT], R&R	With i-stop	S0420BRX	0.9	◆Front bumper assembly, R&R
DRIP MOLDING, R&R	One side	S0422ARX	0.2	
DRIP MOLDING, R&R	Both sides	S0422BRX	0.3	
REAR BELT LINE MOLDING, R&R		S0425XRX	1.9	◆Convertible top assembly, R&R◆ Water leak, Check

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
S05 BONNET (HOOD) & TRUNK LID				
BONNET [HOOD], R&R		S0503XRX	0.5	◆Bonnet, Adjust
BONNET [HOOD] HINGE, R&R	One side,Without i-stop	S0504ARX	2.1	◆Door assembly, R&R◆Front fender (S0601), R&R◆Bonnet, Adjust◆Water leak, Check
BONNET [HOOD] HINGE, R&R	One side,With i-stop	S0504BRX	2.2	◆Door assembly, R&R◆Front fender (S0601), R&R◆Bonnet, Adjust◆Water leak, Check
BONNET [HOOD] HINGE, R&R	Both sides	S0504CRX	3.1	◆Door assembly, R&R◆Front fender (S0601), R&R◆Bonnet, Adjust◆Water leak, Check
TRUNK LID, R&R		S0505XRX	0.5	◆Trunk, Adjust
TRUNK LID HINGE, R&R	One or both sides	S0506XRX	0.5	◆Trunk, Adjust
BONNET [HOOD] LOCK, R&R		S0508XRX	0.6	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	LHD,Without i-stop	S0509ARX	0.9	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	LHD,With i-stop	S0509BRX	1.0	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	RHD,Without i-stop	S0509CRX	0.8	◆Front bumper assembly, R&R
BONNET [HOOD] LOCK RELEASE WIRE, R&R	RHD,With i-stop	S0509DRX	0.9	◆Front bumper assembly, R&R
BONNET [HOOD] CUSHION RUBBER [ONE OR ALL], R&R		S0510XRX	0.2	
TRUNK LID LOCK, R&R	Without i-stop	S0511ARX	0.3	
TRUNK LID LOCK, R&R	With i-stop	S0511BRX	0.4	
TRUNK LID OPENER LEVER, R&R	Opener switch,Without i-stop	S0512ARX	0.2	
TRUNK LID OPENER LEVER, R&R	Opener switch,With i-stop	S0512BRX	0.3	
TRUNK LID RELEASE WIRE, R&R	Convertible top model,Trunk lid opener cable,Without i-stop	S0513ARX	0.3	
TRUNK LID RELEASE WIRE, R&R	Convertible top model,Trunk lid opener cable,With i-stop	S0513BRX	0.3	
TRUNK LID RELEASE WIRE, R&R	Retractable hardtop model,Trunk lid opener cable,Without i-stop	S0513CRX	0.3	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
TRUNK LID RELEASE WIRE, R&R	Retractable hardtop model, Trunk lid opener cable, With i-stop	S0513DRX	0.4	
STRIKER, R&R	Bonnet lock striker	S0514ARX	0.2	
STRIKER, R&R	Trunk lid striker	S0514BRX	0.2	
TRUNK LID WEATHERSTRIP, R&R		S0515XRX	0.3	◆Water leak, Check
TRUNK LID STAY DAMPER, R&R	One or both sides	S0516XRX	0.2	
ENGINE ROOM WEATHERSTRIP [ONE OR ALL], R&R		S0518XRX	0.2	
BONNET [HOOD] INSULATOR, R&R		S0519XRX	0.2	
S06 BODY PANEL & FLOOR ATTACHMENT				
FRONT FENDER, R&R	One side, Without i-stop	S0601ARX	2.0	◆Front bumper assembly, R&R◆Door assembly, R&R
FRONT FENDER, R&R	One side, With i-stop	S0601BRX	2.1	◆Front bumper assembly, R&R◆Door assembly, R&R
FRONT FENDER, R&R	Both sides	S0601CRX	3.0	◆Front bumper assembly, R&R◆Door assembly, R&R
FRONT MUD GUARD, R&R	Front mudguard No.1, One side	S0603ARX	0.3	
FRONT MUD GUARD, R&R	Front mudguard No.1, Both sides	S0603BRX	0.4	
FRONT MUD GUARD, R&R	Front mudguard No.2, One side	S0603CRX	0.3	
FRONT MUD GUARD, R&R	Front mudguard No.2, Both sides	S0603DRX	0.5	
UNDER COVER, R&R		S0604XRX	0.4	
FRAME, R&R	Seat back crossmember, Without i-stop	S0607XRX	1.1	
FRAME, R&R	Seat back crossmember, With i-stop	S0607ARX	1.2	
REAR MUD GUARD, R&R	One side	S0610ARX	0.2	
REAR MUD GUARD, R&R	Both sides	S0610BRX	0.3	
S07 INSTRUMENT PANEL				
CENTER PANEL, R&R	Upper, Without i-stop	S0702ARX	0.3	
CENTER PANEL, R&R	Upper, With i-stop	S0702BRX	0.4	
CENTER PANEL, R&R	Lower	S0702CRX	0.6	
STEERING COLUMN COVER, R&R	Upper	S0706ARX	0.2	
STEERING COLUMN COVER, R&R	Lower	S0706BRX	0.2	
CRUSH PAD, R&R	Without i-stop	S0708ARX	2.4	◆Instrument panel assembly, R&R
CRUSH PAD, R&R	With i-stop	S0708BRX	2.5	◆Instrument panel assembly, R&R
INSTRUMENT PANEL FRAME, R&R	Without i-stop	S0709ARX	2.3	◆Instrument panel assembly, R&R
INSTRUMENT PANEL FRAME, R&R	With i-stop	S0709BRX	2.4	◆Instrument panel assembly, R&R

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
LOWER PANEL, R&R	Driver side	S0710ARX	0.5	
LOWER PANEL, R&R	Passenger side	S0710BRX	0.3	
S08 CONSOLE				
FRONT CONSOLE, R&R		S0802XRX	0.4	
REAR CONSOLE, R&R		S0803XRX	0.3	
CONSOLE BOX, R&R	Without i-stop	S0804ARX	0.3	
CONSOLE BOX, R&R	With i-stop	S0804BRX	0.4	
CONSOLE LID, R&R	Rear console lid	S0806ARX	0.2	
CONSOLE LID, R&R	Back trim lid	S0806BRX	0.2	
CONSOLE LID LOCK, R&R	Back trim lid lock	S0807XRX	0.2	
S09 SEATS & SEAT BELTS				
FRONT SEAT ASSEMBLY, R&R	Driver side,Without i-stop	S0901ARX	0.3	
FRONT SEAT ASSEMBLY, R&R	Driver side,With i-stop	S0901BRX	0.4	
FRONT SEAT ASSEMBLY, R&R	Passenger side,Without occupant classification sensor,Without i-stop	S0901CRX	0.3	
FRONT SEAT ASSEMBLY, R&R	Passenger side,Without occupant classification sensor,With i-stop	S0901DRX	0.4	
FRONT SEAT ASSEMBLY, R&R	Passenger side,With occupant classification sensor,Without i-stop	S0901ERX	0.4	
FRONT SEAT ASSEMBLY, R&R	Passenger side,With occupant classification sensor,With i-stop	S0901FRX	0.5	
FRONT SEAT ASSEMBLY, R&R	Both sides,Without occupant classification sensor,Without i-stop	S0901GRX	0.4	
FRONT SEAT ASSEMBLY, R&R	Both sides,Without occupant classification sensor,With i-stop	S0901HRX	0.5	
FRONT SEAT ASSEMBLY, R&R	Both sides,With occupant classification sensor	S0901JRX	0.6	
FRONT SEAT CUSHION, R&R	Cushion pad,Driver side	S0902ARX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion pad,Passenger side,Without occupant classification sensor	S0902BRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion pad,Passenger side,With occupant classification sensor	S0902CRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion pad,Both sides,Without occupant classification sensor	S0902DRX	1.5	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT CUSHION, R&R	Cushion pad,Both sides,With occupant classification sensor	S0902ERX	1.6	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion support,Driver side	S0902FRX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion support,Passenger side,Without occupant classification sensor	S0902GRX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion support,Passenger side,With occupant classification sensor	S0902HRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion support,Both sides,Without occupant classification sensor	S0902JRX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion support,Both sides,With occupant classification sensor	S0902KRX	1.3	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION, R&R	Cushion supporter,Driver side	S0902LRX	0.3	
FRONT SEAT CUSHION, R&R	Cushion supporter,Passenger side,Without occupant classification sensor	S0902MRX	0.3	
FRONT SEAT CUSHION, R&R	Cushion supporter,Passenger side,With occupant classification sensor	S0902NRX	0.4	
FRONT SEAT CUSHION, R&R	Cushion supporter,Both sides,Without occupant classification sensor	S0902PRX	0.4	
FRONT SEAT CUSHION, R&R	Cushion supporter,Both sides,With occupant classification sensor	S0902QRX	0.5	
FRONT SEAT CUSHION TRIM, R&R	Driver side,Without i-stop	S0903ARX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Driver side,With i-stop	S0903BRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Passenger side,Without occupant classification sensor	S0903CRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Passenger side,With occupant classification sensor,Without i-stop	S0903DRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Passenger side,With occupant classification sensor,With i-stop	S0903ERX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Both sides,Without occupant classification sensor	S0903FRX	1.5	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Both sides,With occupant classification sensor,Without i-stop	S0903GRX	1.6	◆Front seat assembly (S0901), R&R
FRONT SEAT CUSHION TRIM, R&R	Both sides,With occupant classification sensor,With i-stop	S0903HRX	1.7	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT BACK, R&R	Back pad,Driver side	S0904ARX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Passenger side,Without occupant classification sensor	S0904BRX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Passenger side,With occupant classification sensor,Without i-stop	S0904CRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Passenger side,With occupant classification sensor,With i-stop	S0904DRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Both sides,Without occupant classification sensor,Without i-stop	S0904ERX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Both sides,Without occupant classification sensor,With i-stop	S0904FRX	1.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Both sides,With occupant classification sensor,Without i-stop	S0904GRX	1.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back pad,Both sides,With occupant classification sensor,With i-stop	S0904HRX	1.4	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK, R&R	Back support,Driver side,Without i-stop	S0904JRX	0.7	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK, R&R	Back support,Driver side,With i-stop	S0904KRX	0.8	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK, R&R	Back support,Passenger side,Without occupant classification sensor	S0904LRX	0.8	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK, R&R	Back support,Passenger side,With occupant classification sensor	S0904MRX	0.9	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK, R&R	Back support,Both sides,Without occupant classification sensor	S0904NRX	1.4	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK, R&R	Back support,Both sides,With occupant classification sensor	S0904PRX	1.5	◆Front seat back trim (S0905), R&R
FRONT SEAT BACK TRIM, R&R	Driver side	S0905ARX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Passenger side,Without occupant classification sensor,Without i-stop	S0905BRX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Passenger side,Without occupant classification sensor,With i-stop	S0905CRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Passenger side,With occupant classification sensor,Without i-stop	S0905DRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Passenger side,With occupant classification sensor,With i-stop	S0905ERX	0.9	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT BACK TRIM, R&R	Both sides,Without occupant classification sensor,Without i-stop	S0905FRX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Both sides,Without occupant classification sensor,With i-stop	S0905GRX	1.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Both sides,With occupant classification sensor,Without i-stop	S0905HRX	1.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BACK TRIM, R&R	Both sides,With occupant classification sensor,With i-stop	S0905JRX	1.4	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Driver side	S0913ARX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Passenger side,Without occupant classification sensor,Without i-stop	S0913BRX	0.6	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Passenger side,Without occupant classification sensor,With i-stop	S0913CRX	0.7	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Passenger side,With occupant classification sensor	S0913DRX	0.8	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Both sides,Without occupant classification sensor,Without i-stop	S0913ERX	1.1	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Both sides,Without occupant classification sensor,With i-stop	S0913FRX	1.2	◆Front seat assembly (S0901), R&R
FRONT SEAT ADJUSTER, R&R	Both sides,With occupant classification sensor	S0913GRX	1.3	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Driver side,Without i-stop	S0918ARX	0.8	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Driver side,With i-stop	S0918BRX	0.9	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Passenger side,Without occupant classification sensor	S0918CRX	0.8	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Passenger side,With occupant classification sensor,Without i-stop	S0918DRX	0.9	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Passenger side,With occupant classification sensor,With i-stop	S0918ERX	1.0	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Both sides,Without occupant classification sensor	S0918FRX	1.5	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat cushion,Both sides,With occupant classification sensor,Without i-stop	S0918GRX	1.6	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SEAT WARMER, R&R	Seat cushion,Both sides,With occupant classification sensor,With i-stop	S0918HRX	1.7	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Driver side	S0918JRX	0.7	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Passenger side,Without occupant classification sensor,Without i-stop	S0918KRX	0.7	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Passenger side,Without occupant classification sensor,With i-stop	S0918LRX	0.8	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Passenger side,With occupant classification sensor,Without i-stop	S0918MRX	0.8	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Passenger side,With occupant classification sensor,With i-stop	S0918NRX	0.9	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Both sides,Without occupant classification sensor,Without i-stop	S0918PRX	1.2	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Both sides,Without occupant classification sensor,With i-stop	S0918QRX	1.3	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Both sides,With occupant classification sensor,Without i-stop	S0918RRX	1.3	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat back,Both sides,With occupant classification sensor,With i-stop	S0918SRX	1.4	◆Front seat assembly (S0901), R&R
SEAT WARMER, R&R	Seat warmer control unit,Without occupant classification sensor,Without i-stop	S0918TRX	0.3	
SEAT WARMER, R&R	Seat warmer control unit,Without occupant classification sensor,With i-stop	S0918URX	0.4	
SEAT WARMER, R&R	Seat warmer control unit,With occupant classification sensor,Without i-stop	S0918VRX	0.4	
SEAT WARMER, R&R	Seat warmer control unit,With occupant classification sensor,With i-stop	S0918WRX	0.5	
FRONT SEAT BELT [RETRACTOR], R&R	Driver side	S0919ARX	0.4	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT BELT [RETRACTOR], R&R	Passenger side	S0919BRX	0.4	
FRONT SEAT BELT [RETRACTOR], R&R	Both sides,Without i-stop	S0919CRX	0.5	
FRONT SEAT BELT [RETRACTOR], R&R	Both sides,With i-stop	S0919DRX	0.6	
FRONT SEAT SIDE PANEL, R&R	Driver side,Without i-stop	S0927ARX	0.3	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Driver side,With i-stop	S0927BRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Passenger side,Without occupant classification sensor,Without i-stop	S0927CRX	0.3	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Passenger side,Without occupant classification sensor,With i-stop	S0927DRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Passenger side,With occupant classification sensor,Without i-stop	S0927ERX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Passenger side,With occupant classification sensor,With i-stop	S0927FRX	0.5	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Both sides,Without occupant classification sensor,Without i-stop	S0927GRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Both sides,Without occupant classification sensor,With i-stop	S0927HRX	0.5	◆Front seat assembly (S0901), R&R
FRONT SEAT SIDE PANEL, R&R	Both sides,With occupant classification sensor	S0927JRX	0.6	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame,Driver side,Without i-stop	S0928ARX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame,Driver side,With i-stop	S0928BRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame,Passenger side,Without occupant classification sensor,Without i-stop	S0928CRX	0.9	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame,Passenger side,Without occupant classification sensor,With i-stop	S0928DRX	1.0	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame,Passenger side,With occupant classification sensor,Without i-stop	S0928ERX	1.0	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT SEAT FRAME, R&R	Seat back frame, Passenger side, With occupant classification sensor, With i-stop	S0928FRX	1.1	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame, Both sides, Without occupant classification sensor	S0928GRX	1.7	◆Front seat assembly (S0901), R&R
FRONT SEAT FRAME, R&R	Seat back frame, Both sides, With occupant classification sensor	S0928HRX	1.8	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Driver side, Without i-stop	S0944ARX	0.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Driver side, With i-stop	S0944BRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Passenger side, Without occupant classification sensor, Without i-stop	S0944CRX	0.3	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Passenger side, Without occupant classification sensor, With i-stop	S0944DRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Passenger side, With occupant classification sensor, Without i-stop	S0944ERX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Passenger side, With occupant classification sensor, With i-stop	S0944FRX	0.5	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Both sides, Without occupant classification sensor, Without i-stop	S0944GRX	0.4	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Both sides, Without occupant classification sensor, With i-stop	S0944HRX	0.5	◆Front seat assembly (S0901), R&R
FRONT SEAT BELT [BUCKLE], R&R	Both sides, With occupant classification sensor	S0944JRX	0.6	◆Front seat assembly (S0901), R&R
S10 FRONT DOORS				
DOOR BODY, R&R	One side	S1001ARX	1.6	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Both sides, Without i-stop	S1001BRX	3.0	◆Door, Adjust◆Water leak, Check
DOOR BODY, R&R	Both sides, With i-stop	S1001CRX	3.1	◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	One side	S1002ARX	2.1	◆Door assembly, R&R◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
DOOR HINGE, R&R	Both sides	S1002BRX	3.1	◆Door assembly, R&R◆Front fender (S0601), R&R◆Door, Adjust◆Water leak, Check
GLASS & GLASS HOLDER, R&R	One side, Without i-stop	S1003ARX	0.4	◆Door trim assembly, R&R
GLASS & GLASS HOLDER, R&R	One side, With i-stop	S1003BRX	0.5	◆Door trim assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
GLASS & GLASS HOLDER, R&R	Both sides	S1003CRX	0.7	◆Door trim assembly, R&R
GLASS GUIDE, R&R	One side,Without i-stop	S1004ARX	0.6	◆Door trim assembly, R&R
GLASS GUIDE, R&R	One side,With i-stop	S1004BRX	0.7	◆Door trim assembly, R&R
GLASS GUIDE, R&R	Both sides,Without i-stop	S1004CRX	1.1	◆Door trim assembly, R&R
GLASS GUIDE, R&R	Both sides,With i-stop	S1004DRX	1.2	◆Door trim assembly, R&R
GLASS RUN CHANNEL, R&R	One side,Without i-stop	S1005ARX	0.6	◆Door trim assembly, R&R◆Glass & glass holder (S1003), R&R
GLASS RUN CHANNEL, R&R	One side,With i-stop	S1005BRX	0.7	◆Door trim assembly, R&R◆Glass & glass holder (S1003), R&R
GLASS RUN CHANNEL, R&R	Both sides,Without i-stop	S1005CRX	1.1	◆Door trim assembly, R&R◆Glass & glass holder (S1003), R&R
GLASS RUN CHANNEL, R&R	Both sides,With i-stop	S1005DRX	1.2	◆Door trim assembly, R&R◆Glass & glass holder (S1003), R&R
DOOR CHECKER, R&R	One side,Without i-stop	S1006ARX	0.3	◆Door trim assembly, R&R
DOOR CHECKER, R&R	One side,With i-stop	S1006BRX	0.4	◆Door trim assembly, R&R
DOOR CHECKER, R&R	Both sides	S1006CRX	0.5	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	One side,Without i-stop	S1007ARX	0.4	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	One side,With i-stop	S1007BRX	0.5	◆Door trim assembly, R&R
DOOR LOCK ASSEMBLY, R&R	Both sides	S1007CRX	0.7	◆Door trim assembly, R&R
INNER HANDLE, R&R	One side,Without i-stop	S1009ARX	0.2	◆Door trim assembly, R&R
INNER HANDLE, R&R	One side,With i-stop	S1009BRX	0.3	◆Door trim assembly, R&R
INNER HANDLE, R&R	Both sides,Without i-stop	S1009CRX	0.3	◆Door trim assembly, R&R
INNER HANDLE, R&R	Both sides,With i-stop	S1009DRX	0.4	◆Door trim assembly, R&R
INNER HANDLE COVER, R&R	One or both sides	S1010XRX	0.2	
OUTER HANDLE, R&R	Handle bracket,One side,Without i-stop	S1013ARX	0.4	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle bracket,One side,With i-stop	S1013BRX	0.5	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle bracket,Both sides	S1013CRX	0.7	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle,One side,Without i-stop	S1013DRX	0.4	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle,One side,With i-stop	S1013ERX	0.5	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle,Both sides,Without i-stop	S1013FRX	0.6	◆Door trim assembly, R&R
OUTER HANDLE, R&R	Handle,Both sides,With i-stop	S1013GRX	0.7	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Frame or regulator,One side,Without i-stop	S1015ARX	0.6	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Frame or regulator,One side,With i-stop	S1015BRX	0.7	◆Door trim assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
POWER WINDOW MOTOR OR FRAME, R&R	Frame or regulator,Both sides	S1015CRX	1.1	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Motor,One side,Without i-stop	S1015DRX	0.6	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Motor,One side,With i-stop	S1015ERX	0.7	◆Door trim assembly, R&R
POWER WINDOW MOTOR OR FRAME, R&R	Motor,Both sides	S1015FRX	1.1	◆Door trim assembly, R&R
SEAMING WELT, R&R	One or both sides	S1020XRX	0.2	
DOOR WEATHERSTRIP, R&R	One side,Without i-stop	S1021CRX	0.4	◆Door trim assembly, R&R◆Water leak, Check
DOOR WEATHERSTRIP, R&R	One side,With i-stop	S1021DRX	0.5	◆Door trim assembly, R&R◆Water leak, Check
DOOR WEATHERSTRIP, R&R	Both sides,Without i-stop	S1021ERX	0.7	◆Door trim assembly, R&R◆Water leak, Check
DOOR WEATHERSTRIP, R&R	Both sides,With i-stop	S1021FRX	0.8	◆Door trim assembly, R&R◆Water leak, Check
INNER WEATHERSTRIP, R&R	One side	S1023ARX	0.3	◆Door trim assembly, R&R
INNER WEATHERSTRIP, R&R	Both sides	S1023BRX	0.4	◆Door trim assembly, R&R
DOOR TRIM, R&R	One side,Without i-stop	S1026ARX	0.3	
DOOR TRIM, R&R	One side,With i-stop	S1026BRX	0.4	
DOOR TRIM, R&R	Both sides	S1026CRX	0.5	
DOOR STRIKER, R&R	One or both sides	S1032XRX	0.2	
KEYLESS TRANSMITTER BATTERY, R&R		S1038XRX	0.2	
KEYLESS RECEIVER, R&R	Convertible top model	S1041XRX	0.5	◆Side shelf (S1711), R&R
KEYLESS RECEIVER, R&R	Retractable hardtop model,Without i-stop	S1041ARX	0.3	◆Side shelf (S1711), R&R
KEYLESS RECEIVER, R&R	Retractable hardtop model,With i-stop	S1041BRX	0.4	◆Side shelf (S1711), R&R
KEYLESS TRANSMITTER, R&R		S1042XRX	0.2	
KEYLESS ANTENNA [FRONT DOOR], R&R	One side,Without i-stop	S1044ARX	0.4	◆Door trim assembly, R&R
KEYLESS ANTENNA [FRONT DOOR], R&R	One side,With i-stop	S1044BRX	0.5	◆Door trim assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
KEYLESS ANTENNA [FRONT DOOR], R&R	Both sides,Without i-stop	S1044CRX	0.6	◆Door trim assembly, R&R
KEYLESS ANTENNA [FRONT DOOR], R&R	Both sides,With i-stop	S1044DRX	0.7	◆Door trim assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, FRONT], R&R	RHD,Without i-stop	S1045ARX	0.6	
KEYLESS ANTENNA [VEHICLE INTERIOR, FRONT], R&R	RHD,With i-stop	S1045BRX	0.7	
KEYLESS ANTENNA [VEHICLE INTERIOR, FRONT], R&R	LHD,Without i-stop	S1045CRX	0.3	◆Front console assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, FRONT], R&R	LHD,With i-stop	S1045DRX	0.4	◆Front console assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, CENTER], R&R	Without i-stop	S1046ARX	0.3	◆Rear console assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, CENTER], R&R	With i-stop	S1046BRX	0.4	◆Rear console assembly, R&R
KEYLESS ANTENNA [VEHICLE INTERIOR, REAR], R&R	Trunk room,Without i-stop	S1047ARX	0.2	
KEYLESS ANTENNA [VEHICLE INTERIOR, REAR], R&R	Trunk room,With i-stop	S1047BRX	0.3	
KEYLESS ANTENNA [VEHICLE EXTERIOR, REAR], R&R	Without i-stop	S1048ARX	0.7	◆Rear bumper assembly, R&R
KEYLESS ANTENNA [VEHICLE EXTERIOR, REAR], R&R	With i-stop	S1048BRX	0.8	◆Rear bumper assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	One side,Without i-stop	S1050ARX	0.4	◆Door trim assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	One side,With i-stop	S1050BRX	0.5	◆Door trim assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	Both sides,Without i-stop	S1050CRX	0.6	◆Door trim assembly, R&R
REQUEST SWITCH [FRONT DOOR], R&R	Both sides,With i-stop	S1050DRX	0.7	◆Door trim assembly, R&R
REQUEST SWITCH OR OPENER SWITCH [TRUNK LID], R&R	Without i-stop	S1051ARX	0.2	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REQUEST SWITCH OR OPENER SWITCH [TRUNK LID], R&R	With i-stop	S1051BRX	0.3	
KEYLESS BEEPER, R&R		S1053XRX	0.4	◆Cowl grille assembly, R&R
START STOP UNIT, R&R		S1054XRX	0.8	◆Start stop unit configuration
LF CONTROL UNIT, R&R	Without i-stop	S1055ARX	0.2	
LF CONTROL UNIT, R&R	With i-stop	S1055BRX	0.3	
S14 WINDOW GLASSES				
WINDSHIELD GLASS, R&R	Without forward sensing camera (FSC), Without i-stop	S1401ARX	2.7	◆Front window moldings (S0401), R&R ◆Water leak, Check
WINDSHIELD GLASS, R&R	Without forward sensing camera (FSC), With i-stop	S1401BRX	2.8	◆Front window moldings (S0401), R&R ◆Water leak, Check
WINDSHIELD GLASS, R&R	With forward sensing camera (FSC), Without i-stop	S1401CRX	3.0	◆Front window moldings (S0401), R&R ◆Water leak, Check
WINDSHIELD GLASS, R&R	With forward sensing camera (FSC), With i-stop	S1401DRX	3.1	◆Front window moldings (S0401), R&R ◆Water leak, Check
REAR WINDOW GLASS AND/OR WEATHERSTRIP, R&R	Retractable hardtop model, Without i-stop	S1404ARX	2.4	◆Retractable hardtop assembly, R&R ◆Water leak, Check
REAR WINDOW GLASS AND/OR WEATHERSTRIP, R&R	Retractable hardtop model, With i-stop	S1404BRX	2.5	◆Retractable hardtop assembly, R&R ◆Water leak, Check
S16 WIPERS & WASHERS				
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer motor	S1601ARX	0.3	
FRONT WASHER TANK AND/OR MOTOR, R&R	Washer tank	S1601BRX	0.3	
WASHER PIPES AND/OR HOSES [ALL], R&R	Cowl grill to washer nozzle	S1602ARX	0.4	
WASHER PIPES AND/OR HOSES [ALL], R&R	Washer tank to cowl grill	S1602BRX	0.3	
FRONT WASHER NOZZLE [ONE OR ALL], R&R		S1603XRX	0.4	◆Cowl grille assembly, R&R
TANK CAP, R&R		S1604XRX	0.2	
FRONT WIPER BLADE AND ARM [ONE OR ALL], R&R		S1605XRX	0.2	
FRONT WIPER LINK AND/OR FRAME, R&R	Without i-stop	S1606ARX	0.4	◆Cowl grille assembly, R&R ◆Front wiper motor (S1607), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
FRONT WIPER LINK AND/OR FRAME, R&R	With i-stop	S1606BRX	0.5	◆Cowl grille assembly, R&R◆Front wiper motor (S1607), R&R
FRONT WIPER MOTOR, R&R	Without i-stop	S1607ARX	0.4	◆Cowl grille assembly, R&R
FRONT WIPER MOTOR, R&R	With i-stop	S1607BRX	0.5	◆Cowl grille assembly, R&R
FRONT & REAR WIPER ARM COVER [ALL], R&R		S1609XRX	0.2	
WIPER SWITCH, R&R	Without i-stop	S1614ARX	0.2	◆Steering column cover (S0706), R&R
WIPER SWITCH, R&R	With i-stop	S1614BRX	0.3	◆Steering column cover (S0706), R&R
RAIN SENSOR, R&R		S1618XRX	0.3	
S17 TRIMS & MATS				
HEADLINER, R&R	Front header trim,Without i-stop	S1701ARX	0.4	
HEADLINER, R&R	Front header trim,With i-stop	S1701BRX	0.5	
"A" PILLAR TRIM, R&R	One side	S1702ARX	0.2	
"A" PILLAR TRIM, R&R	Both sides,Without i-stop	S1702BRX	0.2	
"A" PILLAR TRIM, R&R	Both sides,With i-stop	S1702CRX	0.3	
FRONT SIDE TRIM, R&R	One or both sides	S1705XRX	0.2	
QUARTER TRIM, R&R	One or both sides	S1706XRX	0.2	
TRUNK SIDE TRIM, R&R	One or both sides,Without i-stop	S1707ARX	0.2	
TRUNK SIDE TRIM, R&R	One or both sides,With i-stop	S1707BRX	0.3	
TRUNK END TRIM, R&R	Without i-stop	S1709ARX	0.2	
TRUNK END TRIM, R&R	With i-stop	S1709BRX	0.3	
PACKAGE TRAY TRIM, R&R	Convertible top model,Rear package trim,Without i-stop	S1710ARX	0.6	
PACKAGE TRAY TRIM, R&R	Convertible top model,Rear package trim,With i-stop	S1710BRX	0.7	
PACKAGE TRAY TRIM, R&R	Retractable hardtop model,Rear package trim,Without i-stop	S1710CRX	0.7	
PACKAGE TRAY TRIM, R&R	Retractable hardtop model,Rear package trim,With i-stop	S1710DRX	0.8	
SIDE SHELF, R&R	Convertible top model,One side,Without i-stop	S1711ARX	0.4	
SIDE SHELF, R&R	Convertible top model,One side,With i-stop	S1711BRX	0.5	
SIDE SHELF, R&R	Convertible top model,Both sides,Without i-stop	S1711CRX	0.7	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SIDE SHELF, R&R	Convertible top model,Both sides,With i-stop	S1711DRX	0.8	
SIDE SHELF, R&R	Retractable hardtop model,One side	S1711ERX	0.3	
SIDE SHELF, R&R	Retractable hardtop model,Both sides	S1711FRX	0.4	
LUGGAGE COMPARTMENT COVER, R&R	Back trim,Without i-stop	S1712ARX	0.6	
LUGGAGE COMPARTMENT COVER, R&R	Back trim,With i-stop	S1712BRX	0.7	
FRONT SCUFF PLATE, R&R	One or both sides	S1713XRX	0.2	
FRONT FLOOR MAT, R&R	One side,Without i-stop	S1715ARX	0.6	
FRONT FLOOR MAT, R&R	One side,With i-stop	S1715BRX	0.7	
FRONT FLOOR MAT, R&R	Both sides,Without i-stop	S1715CRX	0.9	
FRONT FLOOR MAT, R&R	Both sides,With i-stop	S1715DRX	1.0	
TRUNK ROOM MAT, R&R		S1718XRX	0.2	
REAR SIDE TRIM, R&R	One side	S1722ARX	0.2	
REAR SIDE TRIM, R&R	Both sides	S1722BRX	0.3	
REAR FLOOR MAT, R&R	One side	S1726ARX	0.2	
REAR FLOOR MAT, R&R	Both sides	S1726BRX	0.3	
S18 MIRRORS & VISORS				
OUTSIDE MIRROR, R&R	One side,Without i-stop	S1801ARX	0.8	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	One side,With i-stop	S1801BRX	0.9	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	Both sides,Without i-stop	S1801CRX	1.4	◆Door trim assembly, R&R
OUTSIDE MIRROR, R&R	Both sides,With i-stop	S1801DRX	1.5	◆Door trim assembly, R&R
OUTSIDE MIRROR GLASS, R&R	Without blind spot monitoring (BSM),One or both sides	S1802ARX	0.2	
OUTSIDE MIRROR GLASS, R&R	With blind spot monitoring (BSM),One or both sides,Without i-stop	S1802BRX	0.2	
OUTSIDE MIRROR GLASS, R&R	With blind spot monitoring (BSM),One side,With i-stop	S1802CRX	0.2	
OUTSIDE MIRROR GLASS, R&R	With blind spot monitoring (BSM),Both sides,With i-stop	S1802DRX	0.3	
REARVIEW MIRROR, R&R		S1803XRX	0.2	
SUN VISOR, R&R	One or both sides,Without i-stop	S1806ARX	0.4	
SUN VISOR, R&R	One or both sides,With i-stop	S1806BRX	0.5	
STORAGE BOX, R&R	One side	S1808ARX	0.6	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
STORAGE BOX, R&R	Both sides,Without i-stop	S1808BRX	0.6	
STORAGE BOX, R&R	Both sides,With i-stop	S1808CRX	0.7	
S19 SPOILERS				
FRONT AIR DAM SKIRT, R&R	One side	S1901ARX	0.6	◆Front bumper assembly, R&R
FRONT AIR DAM SKIRT, R&R	Both sides,Without i-stop	S1901BRX	0.6	◆Front bumper assembly, R&R
FRONT AIR DAM SKIRT, R&R	Both sides,With i-stop	S1901CRX	0.7	◆Front bumper assembly, R&R
SIDE SPOILER, R&R	One side	S1904ARX	0.3	
SIDE SPOILER, R&R	Both sides	S1904BRX	0.5	
S21 SOFT TOP/HARD TOP				
TOP FABRIC/ROOF PANEL, R&R	Convertible top assembly	S2101CRX	1.8	◆Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop assembly,Without i-stop	S2101DRX	2.2	◆Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop assembly,With i-stop	S2101ERX	2.3	◆Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Convertible top,Top fabric,Without i-stop	S2101ARX	2.6	◆Convertible top assembly, R&R◆ Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Convertible top,Top fabric,With i-stop	S2101BRX	2.7	◆Convertible top assembly, R&R◆ Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop,Front roof panel,Without i-stop	S2101FRX	3.0	◆Retractable hardtop assembly, R&R◆ Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop,Front roof panel,With i-stop	S2101GRX	3.1	◆Retractable hardtop assembly, R&R◆ Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop,Middle roof panel,Without i-stop	S2101HRX	3.0	◆Retractable hardtop assembly, R&R◆ Water leak, Check
TOP FABRIC/ROOF PANEL, R&R	Retractable hardtop,Middle roof panel,With i-stop	S2101JRX	3.1	◆Retractable hardtop assembly, R&R◆ Water leak, Check
HEADLINER, R&R	Convertible top,Header cover	S2102XRX	0.3	
HEADLINER, R&R	Retractable hardtop,Front roof headliner	S2102ARX	0.2	
HEADLINER, R&R	Retractable hardtop,Middle roof headliner	S2102BRX	0.3	
LINK, R&R	Convertible top link,Without i-stop	S2105ARX	3.1	◆Convertible top assembly, R&R◆ Water leak, Check
LINK, R&R	Convertible top link,With i-stop	S2105BRX	3.2	◆Convertible top assembly, R&R◆ Water leak, Check

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
LINK, R&R	Retractable hardtop link,One or both sides,Without i-stop	S2105CRX	3.2	◆ Retractable hardtop assembly, R&R◆ Water leak, Check
LINK, R&R	Retractable hardtop link,One or both sides,With i-stop	S2105DRX	3.3	◆ Retractable hardtop assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Convertible top limit switch,Without i-stop	S2106ARX	1.6	◆ Convertible top assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Convertible top limit switch,With i-stop	S2106BRX	1.7	◆ Convertible top assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop limit switch,Without i-stop	S2106CRX	0.4	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop limit switch,With i-stop	S2106DRX	0.5	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop top lock limit switch,Without i-stop	S2106ERX	0.4	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop top lock limit switch,With i-stop	S2106FRX	0.5	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop motor,One side	S2106GRX	2.3	◆ Retractable hardtop assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop motor,Both sides,Without i-stop	S2106HRX	2.3	◆ Retractable hardtop assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop motor,Both sides,With i-stop	S2106JRX	2.4	◆ Retractable hardtop assembly, R&R◆ Water leak, Check
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop top lock motor,Without i-stop	S2106KRX	0.4	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop top lock motor,With i-stop	S2106LRX	0.5	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop control switch,Without i-stop	S2106MRX	0.3	
MOTOR/LIMIT SWITCH, R&R	Retractable hardtop control switch,With i-stop	S2106NRX	0.4	
HEADER WEATHERSTRIP, R&R	Without i-stop	S2107ARX	0.6	◆ Water leak, Check
HEADER WEATHERSTRIP, R&R	With i-stop	S2107BRX	0.7	◆ Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Convertible top,Link weatherstrip,Front,One side	S2108ARX	0.3	◆ Water leak, Check

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
ROOF PANEL WEATHERSTRIP, R&R	Convertible top,Link weatherstrip,Front,Both sides	S2108BRX	0.4	◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Convertible top,Link weatherstrip,Rear,One side	S2108CRX	1.8	◆Convertible top assembly, R&R◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Convertible top,Link weatherstrip,Rear,Both sides,Without i-stop	S2108DRX	1.9	◆Convertible top assembly, R&R◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Convertible top,Link weatherstrip,Rear,Both sides,With i-stop	S2108ERX	2.0	◆Convertible top assembly, R&R◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Retractable hardtop,Front roof panel weatherstrip,One side	S2108FRX	0.3	◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Retractable hardtop,Front roof panel weatherstrip,Both sides	S2108GRX	0.4	◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Retractable hardtop,Middle roof panel weatherstrip,Without i-stop	S2108HRX	3.0	◆Retractable hardtop assembly, R&R◆Water leak, Check
ROOF PANEL WEATHERSTRIP, R&R	Retractable hardtop,Middle roof panel weatherstrip,With i-stop	S2108JRX	3.1	◆Retractable hardtop assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel (Rear roof) assembly	S2109ARX	1.4	
TOP BOOT/DECK PANEL, R&R	Deck panel link,One side,Without i-stop	S2109BRX	1.5	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel link,One side,With i-stop	S2109CRX	1.5	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel link,Both sides,Without i-stop	S2109DRX	1.5	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel link,Both sides,With i-stop	S2109ERX	1.6	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel motor,One side	S2109FRX	1.4	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel motor,Both sides,Without i-stop	S2109GRX	1.4	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel motor,Both sides,With i-stop	S2109HRX	1.5	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel limit switch,One side,Without i-stop	S2109JRX	1.4	◆Deck panel [Rear roof] assembly, R&R◆Water leak, Check

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
TOP BOOT/DECK PANEL, R&R	Deck panel limit switch,One side,With i-stop	S2109KRX	1.5	◆Deck panel [Rear roof] assembly, R&R ◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Deck panel limit switch,Both sides	S2109LRX	1.5	◆Deck panel [Rear roof] assembly, R&R ◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Roof retainer weatherstrip,One side	S2109MRX	0.3	◆Water leak, Check
TOP BOOT/DECK PANEL, R&R	Roof retainer weatherstrip,Both sides	S2109NRX	0.4	◆Water leak, Check
HOOD LOCK, R&R	Top lock,Convertible top	S2112ARX	0.3	
HOOD LOCK, R&R	Top lock,Retractable hardtop	S2112HRX	0.4	
HOOD LOCK, R&R	Top lock striker,Without i-stop	S2112BRX	0.4	
HOOD LOCK, R&R	Top lock striker,With i-stop	S2112CRX	0.5	
HOOD LOCK, R&R	Female wedge,One or both sides	S2112DRX	0.2	
HOOD LOCK, R&R	Male wedge,One or both sides	S2112ERX	0.3	
HOOD LOCK, R&R	Roof hook,Convertible top,Without i-stop	S2112FRX	0.5	
HOOD LOCK, R&R	Roof hook,Convertible top,With i-stop	S2112GRX	0.6	
HOOD LOCK, R&R	Roof hook,Retractable hardtop,Without i-stop	S2112JRX	1.1	
HOOD LOCK, R&R	Roof hook,Retractable hardtop,With i-stop	S2112KRX	1.2	
CONTROL MODULE, R&R	Retractable hardtop control module,Without i-stop	S2113ARX	0.6	
CONTROL MODULE, R&R	Retractable hardtop control module,With i-stop	S2113BRX	0.7	
S22 AIR BAG SYSTEM				
AIR BAG MODULE, R&R	Front air bag,Driver side,Without i-stop	S2201ARX	0.2	
AIR BAG MODULE, R&R	Front air bag,Driver side,With i-stop	S2201BRX	0.3	
AIR BAG MODULE, R&R	Front air bag,Passenger side,Without i-stop	S2201CRX	0.4	◆Lower panel (S0710), R&R [Passenger side]
AIR BAG MODULE, R&R	Front air bag,Passenger side,With i-stop	S2201DRX	0.5	◆Lower panel (S0710), R&R [Passenger side]
AIR BAG MODULE, R&R	Side air bag,Driver side,Without i-stop	S2201ERX	0.4	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag,Driver side,With i-stop	S2201FRX	0.5	◆Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag,Passenger side,Without occupant classification sensor,Without i-stop	S2201GRX	0.4	◆Front seat assembly (S0901), R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
AIR BAG MODULE, R&R	Side air bag, Passenger side, Without occupant classification sensor, With i-stop	S2201HRX	0.5	◆ Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag, Passenger side, With occupant classification sensor, Without i-stop	S2201JRX	0.5	◆ Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag, Passenger side, With occupant classification sensor, With i-stop	S2201KRX	0.6	◆ Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag, Both sides, Without occupant classification sensor	S2201LRX	0.7	◆ Front seat assembly (S0901), R&R
AIR BAG MODULE, R&R	Side air bag, Both sides, With occupant classification sensor	S2201MRX	0.8	◆ Front seat assembly (S0901), R&R
AIR BAG SENSOR, R&R	Pressure sensor, One side	S2202ARX	0.3	◆ Door trim assembly, R&R
AIR BAG SENSOR, R&R	Pressure sensor, Both sides	S2202BRX	0.4	◆ Door trim assembly, R&R
AIR BAG SENSOR, R&R	Side air bag sensor, One side, Without i-stop	S2202CRX	0.2	
AIR BAG SENSOR, R&R	Side air bag sensor, One side, With i-stop	S2202DRX	0.3	
AIR BAG SENSOR, R&R	Side air bag sensor, Both sides	S2202ERX	0.3	
AIR BAG SENSOR, R&R	Crash zone sensor, One or both sides	S2202FRX	0.6	◆ Front bumper assembly, R&R
AIR BAG CONTROL UNIT, R&R	SAS unit, Without i-stop	S2206ARX	0.7	◆ Luggage compartment cover (S1712), R&R [Back trim]
AIR BAG CONTROL UNIT, R&R	SAS unit, With i-stop	S2206BRX	0.8	◆ Luggage compartment cover (S1712), R&R [Back trim]
ACTIVE BONNET ACTUATOR R&R	One side	S2208ARX	0.2	
ACTIVE BONNET ACTUATOR R&R	Both sides, Without i-stop	S2208BRX	0.2	
ACTIVE BONNET ACTUATOR R&R	Both sides, With i-stop	S2208CRX	0.3	
ACTIVE BONNET SENSOR R&R	One, Without i-stop	S2210ARX	0.4	
ACTIVE BONNET SENSOR R&R	One, With i-stop	S2210BRX	0.5	
ACTIVE BONNET SENSOR R&R	Two	S2210CRX	0.5	
ACTIVE BONNET SENSOR R&R	Three	S2210DRX	0.5	
ACTIVE BONNET SENSOR R&R	All, Without i-stop	S2210ERX	0.5	
ACTIVE BONNET SENSOR R&R	All, With i-stop	S2210FRX	0.6	