

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
R02 FRONT SUSPENSION (WISHBONE)				
UPPER ARM AND/OR UPPER ARM SHAFT, R&R	One side, Without front suspension tower bar	R0201ARX	0.5	◆Front shock absorber assembly, R&R
UPPER ARM AND/OR UPPER ARM SHAFT, R&R	One side, With front suspension tower bar	R0201BRX	0.6	◆Front shock absorber assembly, R&R
UPPER ARM AND/OR UPPER ARM SHAFT, R&R	Both sides, Without front suspension tower bar	R0201CRX	0.8	◆Front shock absorber assembly, R&R
UPPER ARM AND/OR UPPER ARM SHAFT, R&R	Both sides, With front suspension tower bar	R0201DRX	0.9	◆Front shock absorber assembly, R&R
LOWER ARM, R&R	One side	R0202ARX	0.5	
LOWER ARM, R&R	Both sides	R0202BRX	0.9	
COIL SPRING, R&R	One side	R0212ARX	0.7	◆Front shock absorber assembly, R&R
COIL SPRING, R&R	Both sides, Without front suspension tower bar	R0212BRX	1.1	◆Front shock absorber assembly, R&R
COIL SPRING, R&R	Both sides, With front suspension tower bar	R0212CRX	1.2	◆Front shock absorber assembly, R&R
FRONT SHOCK ABSORBER, R&R	One side, Without front suspension tower bar	R0213ARX	0.6	
FRONT SHOCK ABSORBER, R&R	One side, With front suspension tower bar	R0213BRX	0.7	
FRONT SHOCK ABSORBER, R&R	Both sides, Without front suspension tower bar	R0213CRX	1.0	
FRONT SHOCK ABSORBER, R&R	Both sides, With front suspension tower bar	R0213DRX	1.1	
MOUNT BLOCK, R&R	One side, Without front suspension tower bar	R0215ARX	0.6	◆Front shock absorber assembly, R&R
MOUNT BLOCK, R&R	One side, With front suspension tower bar	R0215BRX	0.7	◆Front shock absorber assembly, R&R
MOUNT BLOCK, R&R	Both sides, Without front suspension tower bar	R0215CRX	1.0	◆Front shock absorber assembly, R&R
MOUNT BLOCK, R&R	Both sides, With front suspension tower bar	R0215DRX	1.1	◆Front shock absorber assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
BOUND BUMPER, R&R	One side,Without front suspension tower bar	R0216ARX	0.6	◆Front shock absorber assembly, R&R
BOUND BUMPER, R&R	One side,With front suspension tower bar	R0216BRX	0.7	◆Front shock absorber assembly, R&R
BOUND BUMPER, R&R	Both sides,Without front suspension tower bar	R0216CRX	1.0	◆Front shock absorber assembly, R&R
BOUND BUMPER, R&R	Both sides,With front suspension tower bar	R0216DRX	1.1	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	One side,Without front suspension tower bar	R0217ARX	0.6	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	One side,With front suspension tower bar	R0217BRX	0.7	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	Both sides,Without front suspension tower bar	R0217CRX	1.0	◆Front shock absorber assembly, R&R
SPRING SEAT AND/OR DUST COVER, R&R	Both sides,With front suspension tower bar	R0217DRX	1.1	◆Front shock absorber assembly, R&R
R04 FRONT STABILIZER & CROSSMEMBER				
STABILIZER BAR, R&R	Without front suspension tower bar,Without i-stop	R0401ARX	3.1	◆Front crossmember assembly, R&R◆ Rubber bush and/or plate [body side] (R0403), R&R
STABILIZER BAR, R&R	[Without front suspension tower bar,With i-stop]/[With front suspension tower bar,Without i-stop]	R0401BRX	3.2	◆Front crossmember assembly, R&R◆ Rubber bush and/or plate [body side] (R0403), R&R
STABILIZER BAR, R&R	With front suspension tower bar,With i-stop	R0401CRX	3.3	◆Front crossmember assembly, R&R◆ Rubber bush and/or plate [body side] (R0403), R&R
STABILIZER CONTROL BOLT [CONTROL LINK] AND/OR RUBBER BUSH, R&R	One side	R0402ARX	0.3	
STABILIZER CONTROL BOLT [CONTROL LINK] AND/OR RUBBER BUSH, R&R	Both sides	R0402BRX	0.4	

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	One side, Without front suspension tower bar, Without i-stop	R0403ARX	3.1	◆ Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	[One side, Without front suspension tower bar, With i-stop]/[One side, With front suspension tower bar, Without i-stop]	R0403BRX	3.2	◆ Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	One side, With front suspension tower bar, With i-stop	R0403CRX	3.3	◆ Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	Both sides, Without front suspension tower bar, Without i-stop	R0403DRX	3.1	◆ Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	[Both sides, Without front suspension tower bar, With i-stop]/[Both sides, With front suspension tower bar, Without i-stop]	R0403ERX	3.2	◆ Front crossmember assembly, R&R
RUBBER BUSH AND/OR PLATE [BODY SIDE], R&R	Both sides, With front suspension tower bar, With i-stop	R0403FRX	3.3	◆ Front crossmember assembly, R&R
CROSSMEMBER, R&R	Without i-stop	R0404ARX	3.6	
CROSSMEMBER, R&R	With i-stop	R0404BRX	3.7	
R05 REAR SUSPENSION (STRUT & MULTI-LINK)				
COIL SPRING, R&R	Right side	R0501ARX	0.5	◆ Rear shock absorber assembly, R&R
COIL SPRING, R&R	Left side, Without i-stop, Without auto leveling sensor	R0501DRX	0.6	◆ Rear shock absorber assembly, R&R
COIL SPRING, R&R	[Left side, Without i-stop, With auto leveling sensor]/[Left side, With i-stop]	R0501BRX	0.7	◆ Rear shock absorber assembly, R&R
COIL SPRING, R&R	Both sides, Without i-stop, Without auto leveling sensor	R0501ERX	0.9	◆ Rear shock absorber assembly, R&R
COIL SPRING, R&R	[Both sides, Without i-stop, With auto leveling sensor]/[Both sides, With i-stop]	R0501CRX	1.0	◆ Rear shock absorber assembly, R&R
SPRING UPPER SEAT, R&R	Right side	R0502ARX	0.5	◆ Rear shock absorber assembly, R&R
SPRING UPPER SEAT, R&R	Left side, Without i-stop	R0502BRX	0.6	◆ Rear shock absorber assembly, R&R
SPRING UPPER SEAT, R&R	Left side, With i-stop	R0502CRX	0.7	◆ Rear shock absorber assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
SPRING UPPER SEAT, R&R	<i>Both sides,Without i-stop,Without auto leveling sensor</i>	<i>R0502ERX</i>	<i>0.8</i>	◆Rear shock absorber assembly, R&R
SPRING UPPER SEAT, R&R	<i>[Both sides,Without i-stop,With auto leveling sensor]/[Both sides,With i-stop]</i>	R0502DRX	0.9	◆Rear shock absorber assembly, R&R
BOUND STOP RUBBER, R&R	Right side	R0503ARX	0.5	◆Rear shock absorber assembly, R&R
BOUND STOP RUBBER, R&R	Left side,Without i-stop	R0503BRX	0.6	◆Rear shock absorber assembly, R&R
BOUND STOP RUBBER, R&R	Left side,With i-stop	R0503CRX	0.7	◆Rear shock absorber assembly, R&R
BOUND STOP RUBBER, R&R	<i>Both sides,Without i-stop,Without auto leveling sensor</i>	<i>R0503ERX</i>	<i>0.8</i>	◆Rear shock absorber assembly, R&R
BOUND STOP RUBBER, R&R	<i>[Both sides,Without i-stop,With auto leveling sensor]/[Both sides,With i-stop]</i>	R0503DRX	0.9	◆Rear shock absorber assembly, R&R
TRAILING LINK, R&R	One side	R0504ARX	0.3	
TRAILING LINK, R&R	Both sides	R0504BRX	0.4	
MOUNTING RUBBER, R&R	Right side	R0505ARX	0.5	◆Rear shock absorber assembly, R&R
MOUNTING RUBBER, R&R	Left side,Without i-stop	R0505BRX	0.6	◆Rear shock absorber assembly, R&R
MOUNTING RUBBER, R&R	Left side,With i-stop	R0505CRX	0.7	◆Rear shock absorber assembly, R&R
MOUNTING RUBBER, R&R	<i>Both sides,Without i-stop,Without auto leveling sensor</i>	<i>R0505ERX</i>	<i>0.8</i>	◆Rear shock absorber assembly, R&R
MOUNTING RUBBER, R&R	<i>[Both sides,Without i-stop,With auto leveling sensor]/[Both sides,With i-stop]</i>	R0505DRX	0.9	◆Rear shock absorber assembly, R&R
LATERAL LINK [FRONT], R&R	One side	R0506ARX	0.3	
LATERAL LINK [FRONT], R&R	Both sides	R0506BRX	0.4	
LATERAL LINK [REAR], R&R	One side	R0507ARX	0.3	
LATERAL LINK [REAR], R&R	Both sides	R0507BRX	0.5	
REAR SHOCK ABSORBER, R&R	Right side	R0508ARX	0.5	
REAR SHOCK ABSORBER, R&R	Left side,Without i-stop	R0508BRX	0.6	
REAR SHOCK ABSORBER, R&R	Left side,With i-stop	R0508CRX	0.7	

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
REAR SHOCK ABSORBER, R&R	<i>Both sides,Without i-stop,Without auto leveling sensor</i>	<i>R0508ERX</i>	<i>0.8</i>	
REAR SHOCK ABSORBER, R&R	<i>[Both sides,Without i-stop,With auto leveling sensor]/[Both sides,With i-stop]</i>	R0508DRX	0.9	
CONTROL LINK, R&R	One side,Lower link	R0509ARX	0.3	
CONTROL LINK, R&R	One side,Leading link	R0509BRX	0.3	
CONTROL LINK, R&R	Both sides,Lower link	R0509CRX	0.4	
CONTROL LINK, R&R	Both sides,Leading link	R0509DRX	0.5	
R08 REAR STABILIZER & CROSSMEMBER				
STABILIZER BAR, R&R		R0801XRX	0.5	
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	One side	R0802ARX	0.4	
STABILIZER SUPPORT BRACKET, PLATE AND/OR RUBBER BUSH, R&R	Both sides	R0802BRX	0.5	
STABILIZER CONTROL LINK [CONTROL ROD], R&R	One side	R0803ARX	0.3	
STABILIZER CONTROL LINK [CONTROL ROD], R&R	Both sides	R0803BRX	0.3	
CROSSMEMBER, R&R	<i>[6MT,Without center under cover]/[6MT,With center under cover,Without i-stop]/[6MT,With center under cover,With i-stop,Without auto leveling sensor]</i>	R0804ARX	3.1	◆Propeller shaft assembly (L0101), R&R◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Three way catalytic converter]◆Power plant frame assembly, R&R
CROSSMEMBER, R&R	<i>6MT,With center under cover,With i-stop,With auto leveling sensor</i>	R0804BRX	3.2	◆Propeller shaft assembly (L0101), R&R◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Three way catalytic converter]◆Power plant frame assembly, R&R
CROSSMEMBER, R&R	6AT,Without rear stabilizer bar	R0804CRX	2.8	◆Propeller shaft assembly (L0101), R&R◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Three way catalytic converter]◆Power plant frame assembly, R&R

ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
CROSSMEMBER, R&R	6AT,With rear stabilizer bar,Without i-stop,Without auto leveling sensor	R0804ERX	2.9	◆Propeller shaft assembly (L0101), R&R ◆ Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Three way catalytic converter] ◆Power plant frame assembly, R&R
CROSSMEMBER, R&R	[6AT,With rear stabilizer bar,Without i-stop,With auto leveling sensor]/[6AT,With rear stabilizer bar,With i-stop]	R0804DRX	3.0	◆Propeller shaft assembly (L0101), R&R◆Oxidation/three way/warm up three way catalytic converter (F0702), R&R [Three way catalytic converter] ◆Power plant frame assembly, R&R