

## ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
Z01 WIRE HARNESS				
FRONT HARNESS, R&R	RHD,Without i-stop	Z0101ARX	3.5	
FRONT HARNESS, R&R	RHD,With i-stop	Z0101BRX	3.6	
FRONT HARNESS, R&R	LHD,PCM cover with standard bolts	Z0101CRX	3.5	
FRONT HARNESS, R&R	LHD,PCM cover with shear-off bolts	Z0101DRX	3.7	
INSTRUMENT PANEL HARNESS, R&R	Without i-stop	Z0102ARX	2.2	◆Instrument panel assembly, R&R
INSTRUMENT PANEL HARNESS, R&R	With i-stop	Z0102BRX	2.3	◆Instrument panel assembly, R&R
REAR HARNESS, R&R	Convertible top model,Without i-stop	Z0104ARX	6.3	◆Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	Convertible top model,With i-stop	Z0104BRX	6.4	◆Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<b>Retractable hardtop model,Without i-stop</b>	Z0104CRX	6.9	◆Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
REAR HARNESS, R&R	<b>Retractable hardtop model,With i-stop</b>	Z0104DRX	7.0	◆Heater unit (U0401), R&R ◆ Refrigerant recharge (U0004) not included
ENGINE HARNESS, R&R	Capacitor harness	Z0106ARX	0.9	
ENGINE HARNESS, R&R	Engine harness,Without i-ELOOP system	Z0106BRX	0.7	
ENGINE HARNESS, R&R	Engine harness,With i-ELOOP system	Z0106CRX	0.9	
INTERIOR LAMP HARNESS, R&R	Without i-stop	Z0107ARX	0.4	
INTERIOR LAMP HARNESS, R&R	With i-stop	Z0107BRX	0.5	
FRONT DOOR HARNESS, R&R	One side,Without i-stop	Z0110ARX	0.7	◆Front door assembly, R&R ◆Door trim assembly, R&R
FRONT DOOR HARNESS, R&R	One side,With i-stop	Z0110BRX	0.8	◆Front door assembly, R&R ◆Door trim assembly, R&R
FRONT DOOR HARNESS, R&R	Both sides	Z0110CRX	1.3	◆Front door assembly, R&R ◆Door trim assembly, R&R

## ILLUSTRATION

OPERATION	VARIATION	OPERATION NUMBER	REPAIR TIME	INCLUDES
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	6AT	Z0112ARX	2.1	
EMISSION HARNESS [CONTROL WIRING HARNESS FOR FUEL/IGNITION/EMISSION SYSTEM], R&R	6MT	Z0112BRX	3.2	
EARTH WIRE [ENGINE TO BODY], R&R	Without i-ELOOP system	Z0113ARX	0.3	
EARTH WIRE [ENGINE TO BODY], R&R	With i-ELOOP system	Z0113BRX	0.5	
BATTERY CABLE [POSITIVE], R&R		Z0117XRX	0.5	