



0140-101A
PCM




0140-101B
PCM




COMMON CONNECTOR LIST

00C-2


0140-201A
PCM




0140-201B
PCM



0140-301A
PCM




0140-301B
PCM




COMMON CONNECTOR LIST

00C-4



0140-401A
PCM




0140-401B
PCM




C-01
FRONT HARNESS-EMISSION HARNESS




C-02
FRONT HARNESS-EMISSION HARNESS




(SKYACTIV-G 1.5, 2.0, 2.5 / ATX, SKYACTIV-D 2.2)



C-03
FRONT HARNESS-INSTRUMENT PANEL HARNESS






C-04
FRONT HARNESS-INSTRUMENT PANEL HARNESS




COMMON CONNECTOR LIST


00C-6




C-09
INSTRUMENT PANEL HARNESS-REAR HARNESS




C-10
INSTRUMENT PANEL HARNESS-REAR HARNESS




C-11
INSTRUMENT PANEL HARNESS-REAR HARNESS



C-12
INSTRUMENT PANEL HARNESS-INTERIOR LIGHT NO.2 HARNESS




C-13
INSTRUMENT PANEL HARNESS-INTERIOR LIGHT NO.2 HARNESS




COMMON CONNECTOR LIST

C-14
INSTRUMENT PANEL HARNESS-SHORT CORD

INSTRUMENT PANEL HARNESS




SHORT CORD




(WITHOUT CENTER DISPLAY)

C-15
INSTRUMENT PANEL HARNESS-SHORT CORD

INSTRUMENT PANEL HARNESS




SHORT CORD




(WITH CENTER DISPLAY)

C-16
REAR HARNESS-REAR NO.2 HARNESS

REAR HARNESS




REAR NO.2 HARNESS




(4SD)

REAR HARNESS




REAR NO.2 HARNESS




(5HB)

C-17
REAR HARNESS-REAR NO.2 HARNESS

REAR HARNESS




REAR NO.2 HARNESS




(5HB)

C-18
REAR HARNESS-INTERIOR LIGHT HARNESS

REAR HARNESS





INTERIOR LIGHT HARNESS





(4SD)

C-19
REAR HARNESS-REAR NO.4 HARNESS




C-20
REAR HARNESS-DOOR NO.1 HARNESS




COMMON CONNECTOR LIST

00C-10


C-21
REAR HARNESS-DOOR NO.2 HARNESS




C-22
REAR HARNESS-DOOR NO.4 HARNESS




C-23
REAR HARNESS-DOOR NO.3 HARNESS




C-24
REAR HARNESS-SHORT CORD




C-26
REAR HARNESS-SHORT CORD




C-28
REAR NO.4 HARNESS-SHORT CORD




C-30
DOOR NO.1 HARNESS-SHORT CORD




C-32
JOINT CONNECTOR




C-33
JOINT BOX NO.2




C-34
JOINT BOX NO.2




C-35
JOINT CONNECTOR




C-36
JOINT CONNECTOR




C-37
JOINT CONNECTOR




C-38
JOINT CONNECTOR




C-39
JOINT CONNECTOR




C-40
JOINT CONNECTOR




C-41
JOINT CONNECTOR




C-42
JOINT CONNECTOR




C-43
REAR HARNESS-SHORT CORD




C-44
REAR HARNESS-SHORT CORD




C-45
INSTRUMENT PANEL HARNESS-REAR HARNESS




C-46
FRONT HARNESS-SHORT CORD




C-47
FRONT HARNESS-EMISSION HARNESS




C-48
INSTRUMENT PANEL HARNESS-REAR HARNESS




C-49
REAR HARNESS-SHORT CORD



C-51
JOINT BOX NO.1



C-52
JOINT BOX NO.1




COMMON CONNECTOR LIST

00C-14


C-53
JOINT BOX NO.1

INSTRUMENT PANEL HARNESS




C-54
JOINT BOX NO.1

INSTRUMENT PANEL HARNESS



C-55
JOINT BOX NO.1

REAR HARNESS



C-56
JOINT BOX NO.1

REAR HARNESS

